

# SCREEN SHOT® AUTOMATIC SCREEN DOOR CLOSER

## CLOSE THE SCREEN DOOR!

How many times have you heard this shouted while RVing? The majority of RV screen doors DO NOT come with a retracting hinge, allowing the screen door to hang wide open if it is not shut properly. This invites unwanted pests inside your living space and detracts from the RV's heating and cooling. With our junior RVers constantly going inside, then outside, and then back again, you might find yourself saying, "Close the screen door!" way too often.

Whenever, wherever, we make your experience better.





### SCREEN SHOT® AUTOMATIC SCREEN DOOR CLOSER

## **CLOSE THE SCREEN DOOR!**

#### Patent-pending design



When the screen door is opened, the elastic webbing expands, then automatically pulls the door shut

#### **Easy installation**



Custom anchors fit snugly into the screen door's inner channels while a pair of anchor screws hold it in place

#### Keeps unwanted pests out



The Screen Shot ensures that your screen door closes by itself, every time, keeping unwanted pests out of your RV

#### How to measure



To find the right size, simply measure the inside edges of your entryway door frame (at the widest point) and round up to the nearest even number: 22", 24", 26", 28" or 30". This number will correspond to your RV door's rough opening size and the correct Screen Shot<sup>®</sup> size to purchase.

#### **Additional Features**

- Patent pending design automatically closes the screen door when left opened
- Keeps unwanted pests out of your living space
- Mounting hardware included
- Compatible with Lippert RV entry doors only
- Only for use with Lippert right-hand screen doors. Lippert's entry door identification labels are typically located on the entry door's inside door frame.
- Note: The actual length of the Screen Shot will always be shorter than the listed size, which corresponds to your door's rough opening size

Part #	Description	Door Frame Width
730811	Screen Shot assembly kit	22"
730812	Screen Shot assembly kit	24"
730813	Screen Shot assembly kit	26"
730814	Screen Shot assembly kit	28"
730815	Screen Shot assembly kit	30"