INSTRUCTION MANUAL




Patio Dining Arm Chair


(!) CARE & MAINTENANCE

Please keep this instruction for your future reference.


- Be careful when assembly, avoid hurting the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tighten screws.)
- Please do not exceed the weight limitations of this item.



PARTS




PARTS



PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this chair and learn the exact position of each parts to be assembled.



PRODUCT ASSEMBLY




Loosely attach Part E Back Rail to Part D Chair Back with 2 pcs of Hardware #3 Screw.




2

Loosely attach Part C Seat Board to Part D Chair Leg with 4 pcs of Hardware #4 Screw.




3

Loosely attach both Part I Right Front Leg and Part J Left Front Leg to Part C Seat Board with 2 pcs of Hardware #3 Screw.



Loosely attach both Part A Right Arm Rest and Part B Left Arm Rest to Part D Chair Back with 2pcs of Hardware #3 Screw.

Loosely attach both Part A Right Arm Rest and Part B Left Arm Rest to both Part I Right Front Leg and Part J Left Front Leg with 4 pc sof Hardware #1 Screw.




PRODUCT ASSEMBLY




Loosely attach Part F Right Side Rails between Part D Chair Back and Part I Right Front Leg with 2 pcs of Hardware #4 Screw.

Do the same step for the left side.



6


Loosely attach Part H Connect Rail between Part F Right Side Rail and Part G Left Side Rail with 2 pcs of Hardware #2 Screw.



PRODUCT ASSEMBLY

7

Tighten all the screws when all the parts are loosely attached. Adjust the chair and enjoy it.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.