

Purchase Date: / Order/Customer Reference Numb
--

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products can be requested within the 1-year warranty period. Proof of purchase must be provided. This includes the date of the purchase as well as photos of the product defect. Photos are used to determine the cause of the defect and to provide future quality control. The request will be reviewed, and replacement pieces will be sent at our discretion. For warranty information, visit https://tiny.cc/SunnydazeWarranty

If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

CLASSIC CAFE FOLDING BISTRO CHAIR

Understand and follow the care instructions. Save this document for future reference.



General Care

Regular and proper care will help preserve the quality of your furniture for many Sunnydaze to come!

- **1. Clean Often:** Use a damp cloth to clean as needed and wipe dry with a soft cloth. Never use harsh chemicals or abrasive materials to clean this item.
- **2. Protect:** Always wipe up moisture promptly and dry with a soft cloth. Avoid dragging sharp or rough objects across the surface of your wood furniture.
- **3. Exposure:** Over time, sunlight and weather elements may change the color of natural wood. Avoid leaving wooden furniture in the rain or high-humidity climates as wood can expand and contract with humidity changes; you may need to tighten fittings periodically. If this item is not used for extended periods, cover or store it indoors.
- **4. Winter Care & Storage:** Cover and store the furniture during the winter to protect it from ice and snow. Doing so will preserve the appearance and integrity of the item.