




BODIE ACACIA WOOD PATIO LOVESEAT BOD-5881

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.



**675
pounds**
306 kg

Weight Capacity

No.	PARTS	QTY.
A	 Left Arm Panel	1
B	 Right Arm Panel	1
D	 Backrest	1
F	 Seat	1
I	 Seat Cushion	2
J	 Back Cushion	2
K	 Leg	1

No.	HARDWARE	QTY.
1	 M6x100mm Bolt + Barrel Nut	2
2	 M6x30mm Bolt + Cap	5
3	 M6x35mm Bolt	8



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
Save the packing slip.

INCLUDED TOOLS	
	Hex Key
	M6x35mm Bolt (support bolt for barrel nuts)

NOTE: Save the included tool. Wood expands and contracts with changes in temperature and moisture, which may require hardware to be tightened.

⚠ WARNING ⚠

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

ASSEMBLY

Review all steps and understand assembly before beginning.

Do not fully tighten hardware until all components have been loosely assembled.

STEP 1


A: 1

B: 1

F: 1

1: 2

3: 4



IMPORTANT: Use M6x35mm Bolt (4) to hold the barrel nut so the threaded hole aligns with the pre-drilled hole.


Loosely fasten Left Arm Panel (A) and Right Arm Panel (B) to the front of Seat (F) by hand-tightening M6x100mm Bolt + Barrel Nuts (1).

Loosely fasten the underside of the seat to each arm panel by hand-tightening two M6x35mm Bolts (3).

STEP 2

D: 1


3: 4



Loosely secure the underside of the seat to Backrest (D) by hand-tightening four M6x35mm Bolts.

STEP 3

2: 4




Secure the backrest to each arm panel using two M6x30mm Bolts + Caps (2) on each side.

Finish tightening hardware from all steps.

STEP 4

K: 1

2: 1




Secure Leg (K) to the underside of the seat using one M6x30mm Bolt + Cap (2).

STEP 5

I: 2

J: 2



Place Seat Cushions (I) and Back Cushions (J) on the loveseat.

Care & Maintenance

SAFE USE: Use on a flat, level surface. Do not exceed the weight capacity. Do not stand or climb on the unit.

EXPOSURE: Over time, sunlight and weather elements will cause the wood to oxidize, turning it to a silvery gray color. Additionally, long-term exposure to sun, rain, and high humidity may cause wood swelling. Stress caused from swelling can lead to splitting or cracking, cause hardware to loosen, and glued joints to fail. Maintenance is required to keep wood furniture in tip-top condition.

INSPECT: Periodically check assembly points and tighten fittings as necessary.

CLEANING:

Cushions/Pillows

Brush or vacuum loose dirt from the cushions.

Wipe the cushions down using a soft cloth and lukewarm water. For more stubborn stains, clean with mild soap and cool water, using a soft-bristle brush. Rinse thoroughly and allow to air dry.

Furniture

Identify the direction of the woodgrain. Following the direction of the woodgrain, wipe surfaces with a soft, dry cloth. Do not use harsh chemicals, abrasive materials, or a pressure washer to clean the unit.

CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move to a dry indoor location when not in use. Covering while in storage is recommended to help prevent dust build-up.

MAINTENANCE: If left untreated, the wood may weather. To maintain the appearance, apply a suitable penetrating wood oil (not included) at least once per year or when the wood looks particularly dry.

Before applying a suitable wood oil, clean the unit and bring it into a warm, dry, indoor location. Allow the furniture to dry thoroughly before applying oil; drying may take several days. Only apply oil to wooden surfaces. Apply oil as directed by the wood oil manufacturer.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, OR CLEANING PRODUCTS.

SAFETY STATEMENTS & WARNINGS

- Do not exceed the weight capacity.
- Do not stand on the loveseat.
- Inspect hardware often and tighten as necessary.
- Do not put hot items on or near furniture.
- Do not use this item in the proximity of open flame or flammable/combustible chemicals.
- Keep this unit a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Do not use harsh chemicals or abrasive materials to clean this unit.
- This product is for residential use only; institutional or commercial use will void this warranty.

Any modification to the product or failure to follow recommended care will void the product warranty.


*If you experience issues with assembly or the product was damaged during transit,
please contact our customer service team through one of the methods mentioned at the top of page 1.
Please have the item number and order information ready to expedite response time.*

WARNING:





Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

BODIE ACACIA WOOD PATIO ARMCHAIR BOD-6011

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
Save the packing slip.

No.	PARTS	QTY.
A	 Left Arm Panel	1
B	 Right Arm Panel	1
C	 Backrest	1
E	 Seat	1
I	 Seat Cushion	1
J	 Back Cushion	1

No.	HARDWARE	QTY.
1	 M6x100mm Bolt + Barrel Nut	2
2	 M6x30mm Bolt + Cap	4
3	 M6x35mm Bolt	6

375
pounds
170 kg
Weight Capacity

INCLUDED TOOLS	
	Hex Key
	M6x35mm Bolt (support bolt for barrel nuts)

NOTE: Save the included tool. Wood expands and contracts with changes in temperature and moisture, which may require hardware to be tightened.

! WARNING !

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

ASSEMBLY

STEP 1


A: 1

B: 1

E: 1

1: 2

3: 4



IMPORTANT:

Use M6x35mm Bolt (4) to hold the barrel nut so the threaded hole aligns with the pre-drilled hole.


Loosely fasten Left Arm Panel (A) and Right Arm Panel (B) to the front of Seat (E) by hand-tightening M6x100mm Bolt + Barrel Nuts (1).

Loosely fasten the underside of the seat to each arm panel by hand-tightening two M6x35mm Bolts (3).

STEP 2

C: 1


3: 2



Loosely secure the underside of the seat to Backrest (C) by hand-tightening two M6x35mm Bolts (3).

STEP 3

2: 4




Secure the backrest to each arm panel using two M6x30mm Bolts + Caps (2) on each side.

Finish tightening all hardware.

STEP 4

I: 1

J: 1



Place Seat Cushions (I) and Back Cushions (J) on the chair.

Care & Maintenance

SAFE USE: Use on a flat, level surface. Do not exceed the weight capacity. Do not stand or climb on the unit.

EXPOSURE: Over time, sunlight and weather elements will cause the wood to oxidize, turning it to a silvery gray color. Additionally, long-term exposure to sun, rain, and high humidity may cause wood swelling. Stress caused from swelling can lead to splitting or cracking, cause hardware to loosen, and glued joints to fail. Maintenance is required to keep wood furniture in tip-top condition.

INSPECT: Periodically check assembly points and tighten fittings as necessary.

CLEANING: Identify the direction of the woodgrain. Following the direction of the woodgrain, wipe surfaces with a soft, dry cloth. Do not use harsh chemicals, abrasive materials, or a pressure washer to clean the unit.

CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move to a dry indoor location when not in use.

Covering while in storage is recommended to help prevent dust build-up.

MAINTENANCE: If left untreated, the wood may weather. To maintain the appearance, apply a suitable penetrating wood oil (not included) at least once per year or when the wood looks particularly dry.

Before applying a suitable wood oil, clean the unit and bring it into a dry, warm, indoor location. Allow the unit to dry thoroughly before applying oil; drying may take several days. Only apply oil to wooden surfaces. Apply oil as directed by the wood oil manufacturer.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, OR CLEANING PRODUCTS.

SAFETY STATEMENTS & WARNINGS

- Do not exceed the weight capacity.
- Inspect hardware often and tighten as necessary.
- Do not put hot items on or near furniture.
- Do not use this item in the proximity of open flame or flammable/combustible chemicals.
- Keep this unit a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Do not use harsh chemicals or abrasive materials to clean this unit.
- This product is for residential use only; institutional or commercial use will void this warranty.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during transit, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.