




DESIGNED IN CALIFORNIA



KIDS OUTDOOR POLY ADIRONDACK
ROCKING CHAIR
WITH SIDE TABLE 3-PIECE SET

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

<https://westintrends.com/welcome>



QUESTIONS OR COMMENTS?

If you have questions reach out to
cs@westintrends.com

FOLLOW, SHARE, & LEARN



PRODUCT REGISTRATION

<https://westintrends.com/apps/product-registration>




ACCESSIBILITY - COMMUNITY - VALUE - SUSTAINABILITY

TABLE OF CONTENTS

ASSEMBLY INSTRUCTIONS

Kids Outdoor Poly Adirondack Rocking Chair with Cup Holder	4
Kids Outdoor Poly Adirondack Side Table	11




KIDS OUTDOOR POLY ADIRONDACK
ROCKING CHAIR WITH CUP HOLDER

! CARE & MAINTENANCE

Please keep these instructions for your future reference.

- Be careful when assembling, avoid damaging the painted surface.
- Clean the chair with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



ALLEN WRENCH
(PROVIDED)



WRENCH
(PROVIDED)



CHAIR
300 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 20 MIN.
ASSEMBLY

HARDWARE

1

SCREW
M6 x 50mm



2 PCS

2

SCREW
M6 x 80mm



4 PCS

3

BOLT
M6 x 50mm



4 PCS

4

BOLT
M6 x 45mm



4 PCS

5

BOLT
M6 x 30mm



1 PC

6

M6 WASHER



8 PCS

7

M6 NUT



8 PCS

PARTS

A


CHAIR BACKREST



1 PC

B

CHAIR SEAT



1 PC

C

LEFT CHAIR LEG



1 PC

D

RIGHT CHAIR LEG




1 PC

PARTS

E

RIGHT CHAIR ARM



1 PC

F

LEFT CHAIR ARM



1 PC

G

CUP HOLDER



1 PC

H


ROCKING BASE



2 PCS

PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this chair and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Pick out **Part C Left Chair Leg** and **Part H Rocking Base** from the package.

Attach **Part C Left Chair Leg** to **Part H Rocking Base** as below with 1 pc of **Hardware #2 Screw**.


Do the same to attach **Part D Right Chair Leg** to another **Part H Rocking Base** with 1 pc of **Hardware #2 Screw**.



2

Attach the combined leg **Part (C + H)** to **Part B Chair Seat** with 2 sets of **Hardware #4 Bolt**, **#6 Washer** and **#7 Nut** and 1 set of **Hardware #3 Bolt**, **#6 Washer** and **#7 Nut**.


Pay attention not to tighten the bolts too much. Only tighten by about 70%.



PRODUCT ASSEMBLY


3

Attach another combined leg **Part (D + H)** to **Part B Chair Seat** with 2 sets of **Hardware #4 Bolt, #6 Washer and #7 Nut** and 1 set of **Hardware #3 Bolt, #6 Washer and #7 Nut**.




4

Attach **Part F Left Chair Arm** to **Part C Left Chair Leg** with 1 set of **Hardware #3 Bolt, #6 Washer and #7 Nut**.




5

Attach **Part G Cup Holder** to **Part E Right Chair Arm** with 1 pc of **Hardware #5 Bolt**.



6

Attach **Part E Right Chair Arm** with cup holder to **Part D Right Chair Leg** with 1 set of **Hardware #3 Bolt, #6 Washer and #7 Nut**.




PRODUCT ASSEMBLY

7

Place **Part A Chair Backrest** between two arms as below.

Attach **Part A Chair Backrest** to **Part B Chair Seat** with 2 pcs of **Hardware #1 Screw**.


Attach **Part A Chair Backrest** to **Part F Left Chair Arm** and **Part E Right Chair Arm** with 2 pcs of **Hardware #2 Screw**.



8


Check and tighten all the bolts and screws again to ensure the chair is steady enough.

Enjoy the chair now.





DESIGNED IN CALIFORNIA



KIDS OUTDOOR POLY ADIRONDACK
SIDE TABLE

! CARE & MAINTENANCE

Please keep these instructions for your future reference.

- Be careful when assembling to avoid damaging the top surface.
- Clean the table with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use. Do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Do not overtighten screws. (Insert all screws before tightening screws.)
- Please do not exceed the weight limitations of this item.

TOOLS REQUIRED



ALLEN WRENCH
(PROVIDED)



TABLE
50 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 20 MIN.
ASSEMBLY

HARDWARE

1

SCREW
M6 x 55mm




12 PCS

PARTS

A


TABLE TOP
WITH APRON



1 PC

B


TABLE LEG



4 PCS

C


RAIL I



2 PCS

C


RAIL II



2 PCS

PRODUCT ASSEMBLY - OVERALL VIEW

Look at the overall view of this table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY

1

Insert **Part C Rail I** into the mortise of **Part B Table Legs** and secure it with 1 pc of **Hardware #1 Screw**.


Do not tighten screws too much at this stage.



2


Attach another **Part B Table Legs** to **Part C Rail I** with 1 pc of **Hardware #1 Screw**.

Do the same to attach another set of Part B and Part C.




3

Loosely attach the combined Part B and Part C to the aprons of **Part A Table Top** with 2 pcs of **Hardware #1 Screw**.




4

Attach the other combined Part B and Part C to the aprons of **Part A Table Top** with 2 pcs of **Hardware #1 Screw**.




5

Place the other 2 pcs of **Part D Rail II** between **Part B Table Legs** and attach them with 4 pcs of **Hardware #1 Screw**.



6

Tighten all the screws. Turn over the table and enjoy it now.



REGISTRATION & REFUND POLICY

<https://westintrends.com/apps/product-registration>



<https://westintrends.com/policies/refund-policy>



HAVING TROUBLE

- **Not sure how to assemble or missing pieces?**

Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - **DO NOT exceed 1500 PSI** - this will remove any debris and dirt.