ADJUSTABLE JET FLAME TORCH

Item Number W2015

OWNER'S MANUAL



AWARNING: READ, UNDERSTAND AND FOLLOW ALL INSTRUCTIONS AND WARNINGS BEFORE OPERATING THIS TOOL. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE AND WILL VOID WARRANTY.



TOOL FEATURES

- 1. Flame Guard or Nozzle
- 2. Heat Vents
- 3. Flame Level Adjuster
- 4. Trigger
- 5. Flame Lock
- 6. Gas Filler Valve



SPECIFICATIONS:

Tank Capacity	13g
Max. Operating Time (High / Low)	
Blow Torch Temp.	

Specifications are subject to change without notice.

INSTRUCTIONS FOR USE

Refueling the Torch

Read and understand these refueling instructions before refueling the torch.

- 1. Only use refined Butane fuel when refilling the torch.
- 2. Ensure that the ignition switch is in the "OFF" position and the torch is extinguished before refilling.
- 3. Allow sufficient time for the torch to cool to room temperature before refilling the torch with fuel.
- 4. Refill the torch in a well-ventilated area free of fire or other ignition sources.
- 5. Never smoke while refilling the torch.
- 6. Hold the torch with the fill valve up.
- 7. Invert the fuel canister and insert the fuel canister tip into the fill valve.
- 8. Push the fuel canister and torch together to allow fuel to flow into the torch fuel tank.
- 9. Wear safety glasses and avoid contact with eyes or skin.
- 10. Stop refilling once the fuel begins to overflow.
- 11. Wait 3 minutes to allow fuel gas to stabilize before igniting the torch.

SAFETY INFORMATION

- 1. Always keep the torch out of reach of children.
- Never leave the tool unattended when lit.
- Make sure the torch is completely extinguished after use.
- 4. Ensure that the torch is completely cool before storing.
- 5. Always wear eye protection and gloves when lighting and using the torch.
- 6. Never use a torch that appears to be damaged.
- 7. Keep clear of the torch flame. The flame is difficult to see, so work with caution.
- 8. Do not point the torch towards yourself, others, or flammable objects.
- 9. Never attempt to use a torch as

- a cigarette lighter.
- Do not expose the torch or fuel to temperatures exceeding 120°F/49°C or prolonged sunlight.
- Never use the torch near combustibles such as fuels, rags, towels, paper products, etc.
- 12. Never pierce the fuel tank or expose the torch to fire.
- Do not breathe in fumes, use the torch in a well-ventilated area.
- Do not disassemble or modify the torch in any way, do not alter factory settings.
- Avoid overheating the torch, allow rest periods between each minute of uninterrupted use.

SAFETY INFORMATION

- Using or holding the torch downwards may extinguish the flame.
- 17. Always check that no unintended parts or materials are being heated.
- 18. Ignite the torch away from the face, hands, clothing, or other

- flammable material.
- Always be certain the torch is resting on a level surface reducing the risk of an accidental tip-over.
- Always have a fire extinguisher and a bucket of water near the torch and work area.

On occasion, after printing of our literature is completed, our manufacturers may make changes and/or modifications to merchandise which will not be reflected in this manual. Although we strive to maintain complete and accurate information, it is possible in some instances, that the product may differ slightly from printed specifications. Illustrations are intended for reference only. Actual merchandise may vary. Wilmar is not responsible for typographical errors.

1 YEAR WARRANTY

PERFORMANCE TOOL® extends only the following warranties, and only to original retail purchasers. These warranties give specific legal rights. Except where prohibited by local law, the law of the State of Washington governs all warranties and all exclusions and limitations of warranties and remedies. There may be other rights which vary from state to state.

PERFORMANCE TOOL® warrants the product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provided that product is returned to place of purchase immediately after discovery of defect. After 90 days and up to one year from date of purchase, PERFORMANCE TOOL® will replace at no charge any parts which our examination shall disclose to be defective and under warranty. These warranties shall be valid only when a sales receipt showing the date of purchase accompanies the defective product or defective part (s) being returned. For part (s) after 90 days, please remit your request, postage prepaid to:

PERFORMANCE TOOL, P.O. Box 88259 Tukwila, WA 98138

These warranties exclude blades, bits, punches, dies, bulbs, fuses, hoses, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not designed, or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which has been subject to misuse, neglect, accident or wear and tear incident to normal use and service.

PERFORMANCE TOOL® does not authorize any other person to make any warranty or to assume any liability in connection with its products.

Except for warranties of title and the limited express warranties set forth above, PERFORMANCE TOOL® makes no express or implied warranties of any kind with respect to its products. In particular, PERFORMANCE TOOL® makes no implied warranty of merchantability and no implied warranty of fitness for any particular purpose, except that for goods purchased primarily for personal, family or household use and not for commercial or business use, PERFORMANCE TOOL® makes an implied warranty of merchantability (and, if otherwise applicable, an implied warranty of fitness for a particular purpose), but only for the particular qualities or characteristics, and for the duration, expressly warranted above.

The laws on limitation of implied warranties may differ from state to state, so the above limitations may not apply in all cases.

PERFORMANCE TOOL® shall not be liable for consequential, incidental or special damages resulting from or in any manner related to any product, or to the design, use, or any inability to use the product. The sole and exclusive remedy for a defective product or part shall be the repair, or replacement thereof as provided above. The laws on limitation of remedies or on consequential, incidental or special damages may vary from state to state, so the above limitations may not apply in all cases.

© Copyright 2022 Wilmar, LLC. P.O. Box 88259 Tukwila, WA 98138