

## HOOKER® ASSEMBLY INSTRUCTION

ITEM: 5351-55468 Entertainment Console

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

## HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
А	Ó	Anti - Tip Kit		1 PC



Anti-tip kit is included for use. We recommend installing for safety reason.



Note: Anti-tip kit restraint is provided.

to level console on

uneven floor.

Please follow the instructions enclosed with the pack.