


INSTRUCTION MANUAL



9 Ft. Patio Table Umbrella With Tilt and Crank

V1.0



! CARE & MAINTENANCE

- Clean with lukewarm water, mild detergent & sponge.
- Wipe down the aluminum pole with damp cloth.
- When not in use, cover the umbrella with a protective cover, then store it in a clean, dry, and cool place like a garage or shed to prevent damage and mold.

! SAFETY PRECAUTIONS

- Store the umbrella in windy or stormy weather.
- Be aware that some parts are heavy and have sharp edges.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Do not allow umbrella to flap in the wind as it may cause damage.
- When adjusting umbrella, make sure no person or item is close to the umbrella to avoid injury or damage.

PARTS




PRODUCT ASSEMBLY

1

Check the status of the umbrella before assembly.
Place **Part A Umbrella Body** carefully into **Part B Extend Pole**.


Pay attention that the spring bracket on the end of the umbrella pole is fixed into the small hole at the end of **Part B Extend Pole** after you hear click sound.



PRODUCT ASSEMBLY

2


Insert **Part B Extend Pole** into the umbrella base or the fixing tube on the table.
Tighten the bolt to secure the **Part B Extend Pole**.



PRODUCT ASSEMBLY

3

Loosen the umbrella cloth belt before you open the umbrella.



PRODUCT ASSEMBLY


4

Turn the crank clockwise to open the umbrella and turn it counter-clockwise to close it.

The angle of this umbrella can be easily adjusted by hand for more sunshade area.

Push the silver button shown as below to tilt the umbrella left or right by a max degree of about 30°.

Hold the umbrella when tilting to avoid any injury or damage.



CLEANING TIPS

REGULAR CLEAN: Put the umbrella away in time in windy and rainy weather to extend the service life of the product. Choose a proper weight base to prevent the umbrella from falling over and causing damage. Use a mixture of warm water and mild soap, gently scrub the umbrella cloth with a soft brush to remove any dirt or stains. Wipe the umbrella stand with a damp towel.

QUICK CLEAN: Wipe with a damp towel.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.