


# CANTILEVER UMBRELLA BASE PLATE WEIGHTS

## JLP-255

Read all information carefully before using this product. Save this manual for future reference.



### **HOW TO USE:**

- ▶ Remove the cap from the base plate.
- ▶ Fill the base with sand or water.
- ▶ Replace the cap on the umbrella base.
- ▶ Gently place all four weighted bases snug into the corners of your cantilever umbrella base.

### **IMPORTANT:**

For maximum stability, ensure the base plate weights properly fit your cantilever umbrella stand (not included). Fully fill all four base plates before use; each base plate holds approximately 33 pounds of water or 50 pounds of sand.

Before use, read and understand all safety statements and warnings.

## ⚠ SAFETY STATEMENTS & WARNINGS ⚠

- Always use all four fully-filled base plates to anchor a cantilever umbrella.
- Always close patio umbrellas when not in use and during windy conditions. When filled, base plate weights will hold most cantilever umbrellas in place but may not prevent umbrella uplift during high-wind conditions.
- DO NOT allow water to freeze inside the base. Formation and expansion of ice may crack the base.
- DO NOT stand on the base plates as doing so may damage the unit.
- DO NOT over-tighten the caps as doing so may strip the threads.
- Take care not to drop the base plates as doing so may crack the unit.
- Clean with mild soap and water only; cleaning with harsh chemicals may damage the product and void the product warranty.

**Any modification to the product or failure to follow recommended care will void the product warranty.**

### **⚠ WARNING:**

**Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.**