

SM-TP22 Tripod with 22 In (55.9 cm) Cooking Grate



Parts

Description

A Cooking Grate

B Tripod Top

C Chain

D Tripod Stand



1. Lay out all the parts, make connections with every 2 tripod stands, align the holes to pin (Figure 1/2/3).


Figure 1



Figure 2



Figure 3



2. Align the holes of tripod top to stand's pin (Figure 4/5/6).

Figure 4



Figure 5



Figure 6



3. Hang up the chain, colud adjust the height according to your need. Hang up the cooking grate by chain's hooks. (Figure 8/9).

Figure 8



Figure 9



3. Good Job! Now it's ready for use. Enjoy your great Tripod with 22 In (55.9 cm) Cooking Grate (Figure 11).

Figure 11



WARNING:

- Outdoor use only. Never use in enclosed area. Use in unventilated areas will endanger your life.
- Do not use this unit on or near combustible surfaces or structures such as wood decks, dry leaves or grass, vinyl or wood siding, etc.
- Use on level, non-combustible surface only.
- Keep away from all combustible materials including gasoline and other flammable liquids and vapors.
- Never use flammable accelerants, such as: gasoline, alcohol, paint thinners, kerosene, etc. to start a fire. Serious injury or property damage could result.
- Screen lifting tool may become hot when in use! Failure to wear protective gloves may lead to injury.
- Always wear fire-resistant gloves when handling hot metal screen and lifting tool.
- Keep away from house, garage, balconies, or overhangs.
- Avoid using during dry or windy conditions.
- Keep out of reach of children.
- Do not overfill or use to burn leaves or trash.
- Exercise the same care you would with an open fire.
- Never leave unit unattended while hot or in use.
- · Completely extinguish fire before leaving.
- Ashes can remain hot for a long time after fire is extinguished.
- Dispose of cold ashes properly.
- Any modification of the unit will void product warranty.
 Contact local authorities regarding possible burn restrictions before using product.

Thank you for choosing Sunydaze Décor. If you have any questions, comments or concerns please feel free to contact us by phone at: 888-881-4668, by email: customerservice@serenityhealth.com, or you could also email us via our contact us page at: www.serenityhealth.com/contact-us/.

We stand behind our brand and the quality of the items we sell. We will send new parts, or replace products at our discretion within the one year warranty period. Before we can help, you will need to provide proof of purchase with the date of purchase and photos of the defective merchandise. We will use the photos to determine the cause of defect and for future quality control.