

88 5552 67

Umbrella Stand


IMPORTANT NOTE

Do not use power tools to assemble and only tighten bolts until they are snug.

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damage occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.

Home
Styles



Part List



A.
Top
1 pc.



B.
Base
1 pc.


Hardware List



M12
Nut
1 pc.




Spring Washer
1 pc.



Flat Washer
1 pc.

Assembly Instructions



STEP 1

Attach Top (A) to Base (B) with Flat Washer, Spring Washer and Nut.

Tools required for assembly : 12 MM Wrench or Adjustable Wrench

Home Styles Consumer Assistance : www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319