

If the dartboard is wobbling, adjust the Dartboard Levelers as needed.