


QUANTUM[®]

CSP80PTSE





CSP80PTSE

Quantum CSP80PTSE Spinning Reel Part List

Key #	Description	Part No.	Qty.	Key #	Description	Part No.	Qty.
1	Drag Knob Assembly	RAB332-01	1	21	Line Roller Washer	RAB102-01	2
2	Spool Kit Include	SAB421-01	1	22	Arm Lever Assembly	RAB307-01	1
	2A - Retaining Ring	RAB038-01	1	23	Pin	RAB042-01	1
	2B - Drag Washer "D"	RAB080-01	3	24	Washer	VBP167-01	1
	2C - Drag Washer "B"	RAB033-01	5	25	Screw	BAA108-02	1
	2D - Drag Washer "A"	RAB081-01	3	26	Washer	SAB110-01	1
	2E - Spool Bushing	RAB022-01	1	27	Screw	JX107-03	3
	2F - Spool	SAB021-01	1	28	Ball Bearing Holder Assembly	RAB3190-01	1
	2G - Spool Ball Bearing	CP058-03	1	29	O-Ring	VBP164-01	1
	2H - Washer	RAB065-01	1	30	Pinion Bushing "Top"	RAB214-01	1
	2J - Magnum Drag Washer "A"	SAB081-01	1	31	Pinion Ball Bearing	DP058-02	1
	2K - Magnum Drag Washer "B"	SAB033-01	1	32	One Way Clutch Kit Include	RAB463-01	1
	2M - Magnum Drag Plate	RAB039-01	1		32A - One Way Clutch	VBP063-01	1
	2N - Spool Click Spring	RAB069-01	1		32B - Clutch Sleeve	RAB139-01	1
	2P - Spool Click Spring Holder	SAB114-01	1	33	Gear Kit Include	RAB412-03	1
	2Q - Click Claw	RAB103-01	1		33A - Pinion	RAB011-03	1
	2R - Click Claw Pin	VBP114-01	1		33B - Drive Gear	RAB012-02	1
	2S - Magnum Drag Retainer	RAB225-01	1	34	Pinion Bushing "Bottom"	RAB027-01	1
	2T - Screw	HX107-04	3	35	Handle Screw Cap	RAB054-02	1
3	Spool Adjust Washer	SAB065-01	1	36	Body	RAB001-01	1
4	Main Shaft Assembly	RAB315-01	1	37	Trip Bumper Screw	QW053-07	1
5	Rotor Nut	RAB006-01	2	38	Trip Bumper	RAB119-01	1
6	Screw	JX125-01	1	39	Body Ball Bearing	CP058-01	2
7	Rotor Nut Retainer	RAB118-01	1	40	Drive Gear Adjust Washer	VBP045-01	1
8	Washer	RAB110-01	1	41	Side Cover	RAB023-01	1
9	Rotor Assembly	SAB309-01	1	42	Side Cover Cosmetic Washer	RAB075-01	1
10	Rotor Bushing	RAB106-02	1	43	Side Cover Cosmetic Ring	RAB142-02	1
11	E-Clip	KQ034-01	1	44	Side Cover Screw	VBP057-03	3
12	Rotor Bushing	RAB106-01	1	45	Side Cover Screw	VBP057-04	1
13	Kick Lever	SAB019-01	1	46	O/S Gear Bushing	XP158-01	1
14	Rotor Cover	SAB087-01	1	47	O/S Gear	RAB053-01	1
15	Rotor Cover Screw	QW053-04	2	48	O/S Gear Ball Bearing	CH027-01	1
16	Pin	RAB042-02	1	49	O/S Gear Screw	VBP111-01	1
17	Bushing	SAB106-01	2	50	O/S Slider Assembly	RAB325-01	1
18	Bail Assembly	SAB347-01	1	51	Main Shaft Screw	RQ100-01	2
19	Ball Bearing	CT157-02	2	52	Handle Assembly	SAB318-01	1
20	Line Roller	RAB004-01	1				