
ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL




1 PC





BOX #3 D. SIDE RAILS E. CENTER SUPPORT F. SUPPORT LEG	2 PCS 1 PC 5 PCS	
D	E F	


FULLY ASSEMBLED





HARDWARE KIT PACKED IN BOX #2


NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (8x70mm)		8 PCS
2	ARC WASHER (2x14x26mm)	0	8 PCS
3	LOCK WASHER (M10)	Ø	8 PCS
4	HEX NUT (M8)		8 PCS
5	WRENCH	<i>J</i>	1 PC
6	WOOD SCREW (4x35mm)	***************************************	2 PCS
7	WOOD SCREW (4x25mm)	8	9 PCS
8	ALLEN KEY		1 PC




ASSEMBLY INSTRUCTIONS








STEP 3




- •IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




ASSEMBLY INSTRUCTIONS








STEP 6



STEP 7



ASSEMBLY COMPLETE


PAGE 3 OF 4

INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET *WOOD SCREW (4x35mm) :2 PCS E. CENTER SUPPORT : 1 PC *WOOD SCREW (4x25mm) :9 PCS

F. SUPPORT LEG : 5 PCS

STEP #1:

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.




ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL












BOX #3 D. SIDE RAILS E. CENTER SUPPORT F. SUPPORT LEG	2 PCS 1 PC 5 PCS	
D	E	F

HARDWARE KIT PACKED IN BOX #2

FULLY ASSEMBLED









ASSEMBLY INSTRUCTIONS








STEP 3





STOP


- •IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT. •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




ASSEMBLY INSTRUCTIONS




STEP 5



STEP 6



STEP 7



ASSEMBLY COMPLETE


PAGE 3 OF 4

INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET *WOOD SCREW (4x35mm) :2 PCS E. CENTER SUPPORT : 1 PC *WOOD SCREW (4x25mm) :9 PCS

F. SUPPORT LEG : 5 PCS

STEP #1:

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.




ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL


BOX #1 A. HEADBOARD

1 PC











BOX #3

D. SIDE RAILS2 PCSE. CENTER SUPPORT2 PCSF. SUPPORT LEG10 PCSG. LEFT MATTRESS SPACER1 PC

G. LEFT MATTRESS SPACER 1 PC H. RIGHT MATTRESS SPACER 1 PC




FULLY ASSEMBLED





HARDWARE KIT PACKED IN BOX #2


NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (8x70mm)		8 PCS
2	ARC WASHER (2x14x26mm)		8 PCS
3	LOCK WASHER (M10)	0	8 PCS
4	HEX NUT (M8)		8 PCS
5	WRENCH		1 PC
6	WOOD SCREW (4x35mm)	8	4 PCS
7	WOOD SCREW (4x25mm)	STATE	12 PCS
8	ALLEN BOLT (6x60mm)	9	12 PCS
9	LOCK WASHER (M9)	O	12 PCS
10	FLAT WASHER (M6x13)	0	12 PCS
11	ALLEN KEY		1 PC




ASSEMBLY INSTRUCTIONS



STEP 2




STEP 3





STOP


- •IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6, 7 & 8 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT. •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




ASSEMBLY INSTRUCTIONS




STEP 5






ASSEMBLY INSTRUCTIONS










INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.


PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET :4 PCS *WOOD SCREW (4x35mm) *WOOD SCREW (4x25mm) E. CENTER SUPPORT : 2 PCS :12 PCS *ALLEN BOLT (6x60mm) F. SUPPORT LEG :12 PCS : 10 PCS *LOCK WASHER (M9) :12 PCS G. LEFT MATTRESS SPACER : 1 PC *FLAT WASHER (M6) :12 PCS H. RIGHT MATTRESS SPACER : 1 PC

STEP #1:


USE ALLEN KEY (11) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.




ASSEMBLY INSTRUCTIONS




PARTS AND FITTING PACKAGING DETAIL





BOX #3 D. SIDE RAILS E. CENTER SUPPORT F. SUPPORT LEG	2 PCS 2 PCS 10 PCS	
D	E	

FULLY ASSEMBLED






STEP 1

HARDWARE KIT PACKED IN BOX #2 QTY NO. **DESCRIPTION IMAGE** THREADED BOLT (8x70mm) 8 PCS 1 ARC WASHER (2x14x26mm) 0 2 8 PCS LOCK WASHER (M10) 0 8 PCS 3 4 HEX NUT (M8) 8 PCS 5 **WRENCH** 1 PC WOOD SCREW (4x35mm) 6 4 PCS WOOD SCREW (4x25mm) 7 12 PCS 8 1 PC **ALLEN KEY**


ASSEMBLY INSTRUCTIONS








STEP 3





STOP


- •IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- •IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4




ASSEMBLY INSTRUCTIONS








STEP 6



STEP 7



ASSEMBLY COMPLETE


PAGE 3 OF 4

INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support (F).

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

ASSEMBLY INSTRUCTIONS





AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET *WOOD SCREW (4x35mm) :4 PCS E. CENTER SUPPORT : 2 PCS *WOOD SCREW (4x25mm) :12 PCS

F. SUPPORT LEG : 10 PCS

STEP #1:

USE ALLEN KEY (8) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.

