

Operating Your Quartz Movement Clock

Alkaline battery(s) required (not included).

SETTING THE TIME

1. Install the battery(s) with the positive (+) end located as indicated by the diagram inside the Battery Compartment.
2. Turn the Time Adjusting Knob to adjust the hour and minute hand.

BATTERY REPLACEMENT

If the clock begins to lose time, stops, or the pendulum stops swinging, this is the sign of weak or exhausted batteries. Replace with new alkaline batteries.

PENDULUM SET-UP (for pendulum movements only)

1. Hook the pendulum into the Plastic Hanger located below the clock movement.
2. Gently push pendulum to either side to set in motion -- the pendulum should swing freely.

