






ITEM NAME / NOM D'ITEM: ROCKY SOFA (SEAT)/ROCKY SOFA (ARM)
ITEM # / NO. ITEM: 100531A/100532A/100533A/100531B/100532B/100533B


PARTS LIST / LISTE DES PIÈCES				
100531A/100532A/100533A			100531B/100532B/100533B	
(1)	(2)	(3)	(4)	(5)
 ×1	 ×1	 ×1	 ×2	A. M8 x 60MM  x2
				B. Ø8MM  x6
				C. M5  x1
				D. Ø8 X 18MM  x2
				E. Ø10 X 40MM  x4
				F. WOODEN CAP  x6
				G. M8 X 80MM  x4
				H. Ø4 X 50MM  x3
				I. PASTE PAD  x4
				J. L - BARCKET  x2
				K. Ø4 X 20MM  x4
				L. Ø8MM  x6

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I




II



III



IV



V

