



FINISH® All In 1 Max™

Auto Dish Detergent

Finish® Auto Dish Detergent Powerball All In 1 Max™ Tabs are the World's #1 Recommended Brand.* Easy-to-use, wrapper free & pre-measured dishwasher capsules. No need to pre-soak or pre-rinse with Powerball as it powers away tough grease & scrubs away burnt & dried-on food. Prevents redeposits & provides glass protection. Advanced powder formula cleans tough stains like tea & coffee.

*Recommended by more dishwasher brands worldwide.

Features & Benefits

- No need to pre-rinse or soak
- Cuts through grease, breaks down & lifts away even 24-hour burnt or dried on food
- Contains Glass Protect Action to help prevent glass corrosion & re-deposit
- Easy-to-use, wrapper free & pre-measured dishwasher capsules
- World's #1 Recommended Brand* (*Recommended by more dishwasher brands worldwide)





FINISH® All In 1 Max™

Auto Dish Detergent

Use Instructions

- Insert detergent tab into dishwasher.
- Run wash cycle.

Technical data	FINISH® All In 1 Max™
Color/Form	White & Blue, Solid
pH	9.8
Shelf Life	4 Years

Product	Pack size	Dilution	Product code	
FINISH® All In 1 Max™	16 x 11 count	Ready-to-use	CB204110	🇨🇦
FINISH® All In 1 Max™	6 x 35 count	Ready-to-use	CB367716	🇨🇦
FINISH® All In 1 Max™	4 x 55 count	Ready-to-use	CB367723	🇨🇦
FINISH® All In 1 Max™	4 x 78 count	Ready-to-use	CB367747	🇨🇦
FINISH® All In 1 Max™	4 x 105 count	Ready-to-use	CB367761	🇨🇦

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diverse.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.

FINISH® All In 1 Max™ is a registered trademark of Reckitt Benckiser and is used with their permission.