


PATIO GLIDER BENCH YUK-754

Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.



**SCAN THIS CODE
WITH YOUR
SMARTPHONE
TO VIEW OUR
ASSEMBLY VIDEO**


















Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
Save the packing slip.

**615
pounds**



279 kg

Weight Capacity

No.	PARTS	QTY.
A	 Leg	2
B	 Stretcher	2
C	 Glide Stretcher	2
D	 Seat	1
E	 Backrest	1
F	 Arm Panel	2

No.	HARDWARE	QTY.
H	 M6x60mm Bolt	4
I	 M6x35mm Bolt	8
J	 M6x50mm Bolt	8
K	 M6x70mm Bolt	4
L	 Flat Washer	20
M	 Plastic Washer	8
N	 Nut	24
O	 Nut Cap	24
P	 Bolt Cap	24

TOOLS REQUIRED (not included)

	Hex Key
	Spanner



WARNING

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

NOTE: Over time and with use, the bolts may become loose. Save the included tools for tightening loose hardware.

ASSEMBLY

Review all steps and understand assembly before beginning.


Do not fully tighten hardware until all components have been loosely assembled.

STEP 1

A: 2
B: 2
I: 8
L: 8
N: 8

IMPORTANT:

Ensure legs are installed in the correct direction; the front of each leg is straight, the back of each leg is slightly angled.




Loosely fasten two Legs (A) to two Stretchers (B) using four M6x35mm Bolts (I), Flat Washers (L), and Nuts (N).

STEP 2

C: 2
J: 4
L: 4
M: 4
N: 4

IMPORTANT:


The plastic washers must be installed between the glide stretcher and the leg.



Align the short side of Glide Stretcher (C) with the outside of the legs and loosely secure using two M6x50mm Bolts (J), Flat Washers (L), Plastic Washer (M), and Nuts (N), as shown.

STEP 3


D: 1
F: 2
J: 4
N: 4



Secure two Arm Panels (F) to the middle of Seat (D) using four M6x50mm Bolts (J), and Nuts (N).

STEP 4

E: 1
K: 4
L: 4
N: 4



Secure Backrest (E) to the top of the arm panels using four M6x70mm Bolts (K), Flat Washers (L), and Nuts (N).

STEP 5

H: 4

L: 4

M: 4


N: 4



Assistance is recommended for this step.

IMPORTANT:

Ensure the bench is installed facing the front of the legs.



IMPORTANT:


The plastic washers must be installed between the glide stretcher and the arm panel.

Secure the bottom of the arm panels to the glide stretchers using four M6x60mm Bolts (H), Plastic Washer (M), Flat Washers (L), and Nuts (N), as shown.

STEP 6

O: 24

P: 24



Ensure all hardware is securely fastened. Cover each bolt head using Bolt Cap (P). Cover each Nut using Nut Cap (O).

Care & Maintenance

SAFE USE: For residential use only. Only use on a flat, level surface. Never sit or stand on any part of this unit.

EXPOSURE: Over time, sunlight may cause the finish to fade. Long-term exposure to moisture may cause hardware to rust.

INSPECT: Periodically check assembly points and tighten fittings as necessary.

CLEAN: Hand wash with a soft, damp cloth. Do not use a pressure washer, harsh chemicals or abrasive materials to clean the unit.

CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move to a dry indoor location when not in use. Covering while in storage is recommended to help prevent dust build-up.

SCRATCHES: The powder coating on this product is tough & durable but, even under normal use, some scratching is inevitable. Scratches can be repaired with a rust-resistant paint (not included).

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.



SAFETY STATEMENTS & WARNINGS



- For residential use only. Not for commercial or industrial use.
- Ensure all fittings are tight before use. Periodically check fittings to ensure they remain tight.
- Only use this unit on a flat, level surface.
- Do not exceed the weight capacity of the furniture.
- Never stand or climb on the unit.
- Never allow children to use this product unsupervised.
- Keep furniture a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Never use chemical cleaning products or polishes as doing so may damage the finish.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team directly through one of the methods mentioned at the top of page 1. Please have the item number and order information ready to expedite response time.



WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.