



Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>


CURVED STEEL HAMMOCK CHAIR STAND DL-875











Review all assembly and care information before using this product. Save this manual for future reference.
Assemble components on a soft, clean surface to avoid damaging the finish.





WARNING: Failure to read and follow instructions and safety warnings could result in serious injury or damage to property.

Inspect packaging to ensure all parts are accounted for before disposing of packing materials.
 Save the packing slip.

No.	PARTS		QTY.
A		Base	1
B		Leg (L/R)	2
C		Center Pole (L/R)	2
D		Top Pole (L/R)	2
E		Foot	2
F		M8x60mm Bolt	12
G		M8x25mm Bolt	1
H		Washer	13
I		Locknut	13
J		Anchor Shackle	1

INCLUDED TOOLS	
	Hex Key
	Spanner

⚠ WARNING ⚠

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

**SCAN FOR
HAMMOCK SAFETY TIPS**



<https://tiny.cc/hammock-safety>

⚠ CAUTION ⚠

This unit is not designed for use as a swing. Bouncing, swinging, or any other significant movement while in use may cause the stand to tip, which may lead to serious injury.


This stand must be used on a solid, stable, level surface. Ensure all hardware is securely tightened before every use.

ASSEMBLY


! Carefully read all assembly steps, care instructions, and safety information before using this product. **!**

When choosing a location for your hammock stand, select a smooth, level surface.


Do not install on dangerous terrain or objects such as slopes, on rocks, or in bodies of water.



! **IMPORTANT:** Locknuts must be installed with the nylon insert facing outward. Hand-tighten the nut until you feel resistance, which is caused by the nylon insert. Tools are required to fully tighten locknuts, failure to properly tighten the locknuts may result in product malfunction or personal injury.



TIP: Always fully insert the hex key into the designated notch of the bolt.



If the hex key is not fully inside the notch, the hex key could slip out, causing damage to the bolt head.

Repeated hex key slipping will cause the notch to become rounded, making it difficult or impossible to tighten the bolt with the hex key.

1. Align Legs (B) with Base (A) and loosely secure using four M8x60mm Bolts (F), Washers (H), and Locknuts (I).
2. Align Center Poles (C) with the legs and loosely secure using four M8x60mm Bolts (F), Washers (H), and Locknuts (I).
3. Align Top Poles (D) with the center poles and loosely secure using four M8x60mm Bolts (F), Washers (H), and Locknuts (I).
4. Secure the upper-most hole in the top poles using one M8x25mm Bolt (G), Washer (H), and Locknut (I).
5. Install Anchor Shackle (J) into the bottom hole on the top poles, as shown.
6. Finish tightening all hardware.



HANGING YOUR HAMMOCK CHAIR

(hammock not included)

⚠ IMPORTANT: This hammock stand accommodates many (but not all) hanging chair styles. This stand is not suited for most hand-woven or rope-style hanging chairs.

The seat height of the hanging hammock chair should be at a height where the user can enter and exit the hammock chair safely.

Always enter and exit hammocks slowly; moving too quickly can cause the hammock chair and/or stand to tip over. **This stand is not designed for swinging or excessive movements, as doing so may cause the stand to tip over.** It is okay to very gently sway in your hanging hammock chair as long as both feet remain firmly in contact with the ground.



ADJUSTING HAMMOCK HEIGHT

(hammock chair and hanging hardware not included)

Additional hanging hardware (not included) may be required to hang your hammock chair.

If your chair is too high, you may need to purchase Grade 30 Galvanized Chain (not included) to achieve a safe hanging height.

If a chain is used, the number of chain links between the anchor shackle will determine how high or low your hammock chair hangs.

More links = closer to the ground

Less links = higher off the ground

Adjust height as needed; take into account the type of chair and the users' height and weight. The hammock stand and chair will be lower to the ground after weight is added. Note, it is normal for the stand to bend slightly downward after weight is added.

BEFORE USE

- Ensure all hardware is securely fastened.
- Ensure the hanging hammock chair stand on a firm, flat, and level surface.
- Carefully read all use, care, and safety information to ensure the stand is used safely.
- Always enter and exit the hammock slowly.
- Do not swing in your hammock chair when used with this stand!

GENERAL USE & CARE



WARNING: Do not use if parts are missing, worn, or damaged.



WARNING: Never leave a hammock hanging on this stand while not in use.



WARNING: Do not allow children to use this product without constant adult supervision.



WARNING: Always keep weight centered over the base when using this product.

SAFE USE: Follow all safety statements and warnings. Always move slowly when getting in and out of any hammock. Do not use this chair stand for swinging. Swinging, bouncing, jumping, and other excessive movements may cause the stand to tip over or break, which may result in serious injury or property damage.

Always remove your hammock from the stand while not in use.

CHILDREN: This stand is only to be used by adults and person(s) with developed motor skills who also understand the potential dangers if hammocks and hammock stands are misused.

Supervise children at all times. Never allow small or young children to enter or exit a hanging hammock chair without adult assistance. Never allow or encourage children to sleep or play in a hammock. Always teach and practice safe hammock use, with and without a hammock stand.

INSPECTION: Frequently check the stand to confirm all hardware is securely fastened. Do not use the stand if parts are missing, broken, damaged, or worn. Don't forget, it is also important to inspect your hammock chair (not included) before every use.

COVER AND STORE: Protect your investment by covering or storing this stand when not in use. Avoid long-term exposure to precipitation and high-moisture areas. Covering the stand will protect it from damages caused by water and sunlight. Store in a cool, dry location.


CLEANING: Wipe surfaces with a soft cloth and warm water. Dry the stand after cleaning to prevent rust.

SCRATCHES: The powder coating on the stand is tough and durable, but even under normal use, some scratching is inevitable. To avoid excessive rust, wipe scratched areas as needed to remove moisture.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE APPLICATION OF CHEMICAL TREATMENTS, PROTECTIVE COATINGS, TOUCH-UP PAINT, OR CLEANING PRODUCTS.

! SAFETY STATEMENTS & WARNINGS !

- Do not exceed the weight capacity.
- Do not swing, bounce, jump, twist, or spin in any hanging chair when using this chair stand. This stand is designed for sitting calmly in a hammock chair. **Chair not included.**
- When in use, the hanging chair (not included) should remain inside the base area at all times. A diagram of the base area is shown on the right.
- Always inspect the stand and hardware for weakness and damage before each use.
- Do not stand or climb on any part of this unit.
- Do not allow children to use this product without adult supervision. Never leave children unattended.



Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.