

205106

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.
Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Unscrew the canopy loop ring (4) from the mounting bar (8).
2. Open the lamp arms (1) slightly and make sure each arm is evenly spaced apart.
3. Thread the stem (2) onto the fixture assembly (10).
4. Attach one end of the quick link (3) with chain to the loop on the top of stem (2). Fully close the quick link (3).
5. Weave the fixture wires through chain links, skipping every other chain link, the canopy loop ring (4), canopy loop (5) and canopy (6) into the junction box.
6. Attach another end of the quick link (3) onto the canopy loop (5). Fully close the quick link (3).
7. Attach the mounting bar (8) with box screws (7) to the outlet box.
8. Attach the decorative crystal (11) and (12) onto the ring of the fixture assembly (10).
9. Pull out the outlet wire and ground wire from the outlet box.

Make wire connections with wire nut (9).

--Connect the ribbed wire w/o marking (Neutral wire) or white wire from the light to the white wire from power source.

--Connect the wire with the markings and smooth surface (Live wire) or black wire from the light to the black wire from power source.

--Wrap the grounding wire (green wire or bare copper wire) from the light around the green screw on the mounting bar (8), then connect it to the grounding conductor from power source.

10. Install three 60W Max. B10 bulbs: (bulb not included)
(Don't exceed the maximum capacity recommended on the socket).

