

DORSEY EXTENSION DINING TABLE


ASSEMBLY INSTRUCTIONS



PARTS PACKING CONFIGURATIONS


A. TABLE TOP

1 PC




B. EXTENSION LEAF

1 PC




C. LEG

2 PCS





FULLY ASSEMBLED




HARDWARE KIT PACKED IN BOX

NO.	DESCRIPTION	IMAGE	QTY
1	ALLEN BOLT (5/16"x60mm) with SPRING WASHER (5/16") and FLAT WASHER (5/16")		16 SETS
2	ALLEN KEY		1 PC




STEP 1




DORSEY EXTENSION DINING TABLE ASSEMBLY INSTRUCTIONS



STEP 2



STEP 3



DORSEY EXTENSION DINING TABLE ASSEMBLY INSTRUCTIONS



STEP 4

