

BOX 1 - H	IEADBOAF	RD-FOOTBOARD		BOX 2 - S	IDERAILS	
PART NO.	IMAGE	DESCRIPTION	QUANTITY	PART NO.	IMAGE	
A		HEADBOARD	1	С		SID
				D	W W W	CEI
В		FOOTBOARD	1	E		LEC
В		FOOTBOARD	1	BOX 3 - SLAT ROLL		
HARDWA	RE KIT PA	CKED IN BOX 1		PART NO.	IMAGE	
1		ALLEN BOLT (8X60mm)	8	F		SLA
2	0	SPRING WASHER (M8)	8		<u> </u>	
3	0	FLAT WASHER (M8)	8		FU	JLLY
4	(4) The state of t	WOOD SCREW (8X30mm)	9			
5	9	ALLEN BOLT (6X40mm)	11			

YOUR BOX MAY CONTAIN EXTRA HARDWARE

ALLEN KEY



6









1


ASSEMBLE ON A SOFT SURFACE

PART NO. IMAGE DESCRIPTION QUANTITY C SIDERAIL 2 D CENTER SLAT 1 E LEG SUPPORT 4


<u>PART NO.</u>	IMAGE	DESCRIPTION	QUANTITY
F		SLAT ROLL	1


















STOP

- IF USING BED FRAME WITH ADJUSTABLE MATTRESS BASE, SKIP TO APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION CONTINUE TO STEP 4.







STEP 5:




STEP 6:



STEP 7:




STEP 8:







STEP 9:




STEP 10:



STEP 11:



STEP 12:



ASSEMBLY COMPLETE

INSTRUCTIONS FOR ADJUSTING LEVELER:


Position the bed in your space and locate the leveler under each leg support (**E**).

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.



PENNY FULL/QUEEN/E.KING BED APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT



AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

D. CENTER SLAT 1PC
E. LEG SUPPORT 4PCS
F. SLAT ROLL 1SET

4. WOOD SCREW (8X30mm) 9PCS 5. ALLEN BOLT (6X40mm) 11PCS

STEP 1:

USE ALLEN KEY **(6)** TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.



BOX 1 - HEADBOARD-FOOTBOARD				
PART NO.	IMAGE	DESCRIPTION	QUANTITY	
A		HEADBOARD	1	
В		FOOTBOARD	1	
HARDWARE KIT PACKED IN BOX 1				
1		ALLEN BOLT (8X60mm)	8	
2		SPRING WASHER (M8)	8	
3	0	FLAT WASHER (M8)	8	
4	(4)	WOOD SCREW (8X30mm)	9	
5	9	ALLEN BOLT (6X40mm)	11	
6		ALLEN KEY	1	

BOX 2 - SIDERAILS				
PART NO.	IMAGE	DESCRIPTION	QUANTITY	
С		SIDERAIL	2	
D	8 1 1 8	CENTER SLAT	1	
E	^	LEG SUPPORT	4	

BOX 3 - SLAT ROLL

<u>PART NO.</u>	IMAGE	DESCRIPTION	QUANTITY
F		SLAT ROLL	1

YOUR BOX MAY CONTAIN EXTRA HARDWARE












ASSEMBLE ON A SOFT SURFACE

FULLY ASSEMBLED













STOP

- IF USING BED FRAME WITH ADJUSTABLE MATTRESS BASE, SKIP TO APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION CONTINUE TO STEP 4.







STEP 5:




STEP 6:



STEP 7:




STEP 8:







STEP 9:




STEP 10:



STEP 11:



STEP 12:



INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each leg support (**E**).


Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.

UPDATED: JULY 4TH, 2024

MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.



PENNY C.KING BED APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT



AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

D. CENTER SLAT 1PC
E. LEG SUPPORT 4PCS
F. SLAT ROLL 1SET

4. WOOD SCREW (8X30mm) 9PCS 5. ALLEN BOLT (6X40mm) 11PCS

STEP 1:

USE ALLEN KEY **(6)** TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION.