



SOLO ASSIST

GETTING STARTED



Thank you for choosing SKLZ Solo Assist. We are dedicated to providing you with the best tools and instruction possible to help you unleash your athletic potential. If there is anything else we can do to help, don't hesitate to send us an email at customerservice@sklz.com or give us a call at **1-877-225-7275**.

BEFORE YOU BEGIN:

- Read all setup and usage instructions carefully before using. If the setup and/or instructions are not followed correctly, it could result in injury or damage to the product.
- Adult assembly is recommended.
- Make sure you have all Solo Assist components. If you are missing anything, please contact SKLZ customer service toll free at **1-877-225-7275**.

⚠️WARNING:

- Do not climb or hang on the Solo Assist.
- Keep away from fire and heat sources.
- Not suitable for children under 3 years of age.
- Regularly check for wear and tear. Stop using the Solo Assist if any part of it breaks or tears. Failure to do so could result in injury.
- Solo Assist is a rebounder and will propel the ball towards the thrower at high speeds. Be sure that the user and observers are safely positioned before using.
- The net will be under extreme tension and must be attached carefully. Adult assembly is strongly recommended.
- To avoid pinching hazards, keep fingers clear when connecting poles and net bungees during assembly and plastic clips on the rear frame.

IDEA SUBMISSION


If you have an idea for a new and innovative sports training product, visit SKLZ.com to submit your concept. Some restrictions may apply.

1 YEAR LIMITED WARRANTY


This warranty does not cover damages resulting from accident, misuse, abuse or lost merchandise, and is only valid in the USA. Need proof of purchase for warranty coverage. **Questions? Email customerservice@sklz.com or call toll free 1-877-225-7275.**

Made in China. ©2015 Pro Performance Sports, LLC. All rights reserved. Manufactured and distributed by SKLZ/Pro Performance Sports; 2081 Faraday Avenue, Carlsbad, CA 92008 USA. SKLZ is a registered trademark of Pro Performance Sports, LLC, its subsidiaries and affiliates. Product features, appearance and specifications may be subject to change without notice. Unauthorized duplication is a violation of applicable local and international laws.

PARTS




ASSEMBLY




1

Slide the Top Left (A) through the black sleeve on Left Leg (E). Repeat with Top Right (B) and Right Leg (F). Connect parts (A) and (B) using the spring clip.




2

Slide Foot (G) onto Left Leg (E) and repeat with the Right Leg (F). Then connect parts (E) and (F) using the spring clip.



3

Slide Bottom Left (C) and Bottom Right (D) into the last remaining Foot (G). Push in from both sides until (C) connects with (D).




4

Slide the Bottom Right (D) into Top Right (B), DO NOT secure with spring clip. Repeat on the left side, DO NOT secure with spring clip. Now that both bottom poles are resting in the top poles, secure with the spring clips.



5

Put the unit into a standing position as shown in the picture above. Unclip the yellow clips from the back legs and secure them between the yellow tabs on the front of the frame.



6

Lay out the Net (I), then connect the corners of the Net to the frame using the Bungees (H). See the image above for suggested connection points for the rest of the Net. When complete there should be 5 Bungees on top, 5 on each side and 2 on the bottom.