

# FLEXSTEEL®




## W1029-826

### BUFFET

#### IMPORTANT


Carefully remove all parts from the carton, and put them individually on a soft cloth to prevent damage to the parts.

We have taken great care in the design of this product and request that you carefully and accurately follow our assembly instructions to ensure proper set-up.




Part List


Assembly Instructions 1/5




A. Box  
1 piece



B. Left Leg  
1 piece




C. Right Leg  
1 piece



D. Stretcher  
1 piece




E. Support Leg  
2 pieces




F. Shelf  
4 pieces


Hardware List




Large Bolt  
Ø5/16"-18 UNC x 1-3/4"  
2 pieces




Small Bolt  
Ø5/16"-18 UNC x 1-1/4"  
8 pieces




Spring Washer  
Ø5/16" x 1.5mm  
10 pieces




Flat Washer  
Ø5/16" x Ø19mm x 1.5mm  
10 pieces



Hex Key  
5/32"  
1 piece



Shelf Bracket  
16 pieces



Anti-Tip Kit  
1 set

# FLEXSTEEL®


## Assembly Instructions 2/5

### IMPORTANT NOTES

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults.


### STEP 1

Open the doors of the Box (A) and remove the Legs (B) and (C) and Shelves (F). Close both doors once removed. (See Figure 1)



### STEP 2

Connect the Stretcher (D) to the Left Leg (B) and Right Leg (C) using Large Bolts, Spring Washers, and Flat Washers, only tightening by hand. Do not fully tighten the bolts with the Hex Key at this time. (See Figure 2)



# FLEXSTEEL®


## Assembly Instructions 3/5

### IMPORTANT NOTES

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults.


### STEP 3

Connect the Support Legs (E) to Box (A) by turning them by hand clockwise until tight. (See Figure 3)



### STEP 4

Fix Left Leg (B) and Right Leg (C) to the Box (A). Insert Small Bolt, Spring Washers, Flat Washers and fully tighten up all the bolts Hex Key. Fully tighten all of the bolts from the previous steps. (See Figure 4)



# FLEXSTEEL®


## Assembly Instructions 4/5

### IMPORTANT NOTES

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults.


### STEP 5

Flip the Buffet upright. Insert Shelf Brackets to side panels at the desired shelf height. (See Figure 5)



### STEP 6

Place shelf panel (F) on shelf brackets, flip over shelf panel for wood shelf or wine rack use. (See Figure 6)



# FLEXSTEEL®

## Assembly Instructions 5/5

### IMPORTANT NOTES

- Do not tighten up all the bolts until each part is properly assembled.
- Keep the Hex Key in a safe place as you may need to tighten up the bolts in the future.
- Use a soft cloth between these parts and the floor.
- We recommend this product be assembled by at least two adults.

### STEP 7

Adjust the levelers on the legs until the furniture is leveled. (See Figure 7)

The drawers can be adjusted up or down as necessary using the adjustment knob under the drawers on the drawer glides. (See Figure 8)

Pull out the slide latch at the bottom of the drawer and lift the drawer up to remove it. (See Figure 9)

NOTE: There is a tip restraint kit provided on the back of this product. Take care to read the instructions thoroughly and install it immediately when placed in the home.




Figure 7

Adjustable leveler





Figure 9




Figure 8

### CARE INSTRUCTIONS

- To avoid scratches, do not place sharp or jagged objects directly on the table top.
- Do not place hot items directly on the table top.
- Use placemats or trivets under hot items and coasters under beverages to prevent marks and stains.
- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc.

For Parts or Customer Service call

toll-free:

1-888-415-3979

Monday-Friday

8:00 a.m. -5:00 p.m.

(Central Time)

Email:

customersolutions@flexsteel.com

www.flexsteel.com