



3-Hole Bag Toss



Please keep this instruction manual for future reference

If you have any problems with your new product, please contact Triumph Sports USA at 1-866-815-4173, or e-mail us at csr@triumphsportsusa.com for any technical support or warranty issues.

90-Day Triumph Sports USA, Inc. (TSU) Game Warranty

All TSU games have a 90-day from date of purchase warranty. This warrants the retail purchaser for any TSU game purchased to be free from any defect in materials and construction for 90 days from the date of purchase. Normal play wear and usage is not covered under the warranty, nor is wear or damage due to improper use of the TSU game. This will void any and all TSU warranties.

A PURCHASE RECEIPT (or other proof of purchase date) will be required before any warranty service is initiated. All requests for warranty service can be submitted by email, in writing or by contacting our Customer Service Department at: 1-866-815-4173 or email us at csr@triumphsportsusa.com.

IMPORTANT NOTICE! Please contact us before returning the product to the store.

Warnings



WARNING: Choking Hazard--Small Parts.
Not for children under 3 years of age.

This is not a child's toy. Adult supervision is required for children playing this game. Please read instructions carefully. Proper use of this set can prevent damage or injury.

Be sure to check out all the exciting games  has to offer.

Visit our web site at:

www.triumphsportsusa.com



BILLIARDS



DARTS



GAME TABLES



CASINO



OUTDOOR GAMES








DARTBOARDS

Triumph Sports USA
Milwaukee, WI

www.triumphsportsusa.com

©2012 Triumph Sports USA. All Rights Reserved.

Parts List

<p>1</p>  <p>Game Platform 2 pcs</p>	<p>2</p>  <p>Black Bag 3 pcs</p>	<p>3</p>  <p>Orange Bag 3 pcs</p>	<p>4</p>  <p>Front Leg 4 pcs</p>
<p>5</p>  <p>Back Leg 4 pcs</p>			

Game Rules



3-Hole Bag Toss

2 to 8 players

Preparation: Set the boards 18 feet apart from the front of the boards on even ground. (Adjust as needed for children).

Game Rules:

Each team gets 3 bags to throw. Play continues alternating player/team until each player has tossed their bags.

With four players, team members stand at opposite ends and may throw from either side of the box.

Players must throw from behind the front of the boxes, which is the foul line. If a player crosses the foul line the throw does not count and the bag is removed from play.

Each team alternates throws beginning with the team that scored last.

Scoring:

Points are scored when a player lands a bag in the hole.

Top Holes = 3 Points

Middle Holes = 2 Points

Bottom Hole = 1 Point

No Score - Bags that miss the hole or bounce off the ground do not count in scoring.

To Win - Throwing your Bean Bags into the 1, 2, and 3 point holes. First Player/Team to reach 21 points wins!