



31.5" OUTDOOR SQUARE DINING TABLE

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com

FOLLOW, SHARE, & LEARN













PRODUCT REGISTRATION

https://westintrends.com/apps/product-registration




(!) CARE & MAINTENANCE

- Be careful when assembly, avoid hurting the product.
- Clean the dust with lukewarm water, mild detergent & soft cloth.
- Firmly secure all bolts before use, do not use any part of this item as a step ladder.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.






PARTS



PRODUCT ASSEMBLY - OVERALL VIEW


Look at the overall view of this table and learn the exact position of each part to be assembled.



PRODUCT ASSEMBLY


1

Slide Part B2 Leg II on Part B1 Leg I as shown below. Make sure the top of Part B1 & B2 are aligned and gently tap with a rubber mallet if necessary.




2

Turn over the legs. Attach 2pcs of **Hardware #1 Self-tapping Screws** on the bottom of **Part B1 Leg I** by using an screwdriver. 100% tighten at this step.



3

Put Part A Table Top upside down on a clean aground. Attach Combined Part (B1+B2) on the bottom of Part A Table Top with 8 sets of Hardware (#2 Bolt + #3 Lock Washer + #4 Flat Washer) by using an allen wrench. 100% tighten at this step.




PRODUCT ASSEMBLY



Adjust the feet levelers on the bottom of the legs for perfect balance.

Enjoy the table now.



adjustable feet leveler

REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy



HAVING TROUBLE

• Not sure how to assemble or missing pieces?
Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.