Honeywell Home

Expansion and Accessories for Residential and Commercial Controls

Hardwired Expansion for VISTA-15P, VISTA-20P and VISTA-21iP

4219 - Wired Zone Expander

4229 – Wired Zone Expander/Relay Board

4204 – Relay Module



Wireless Receivers



5881ENL - Eight Zone Receiver

5881ENM - 16 Zone Receiver

5881ENH – Panel Dependent Receiver (Unlimited Zones)

5881ENHC – Commercial Wireless Receiver

5883H - High Security Transceiver Module

5800RP – Wireless Repeater

Connected Home Expansion



TUXWIFIW/TUXWIFIS – Tuxedo Touch™ with Wi-Fi®

VAM/VAM-WH – VISTA Automation Module ZWSTAT – Z-Wave® Thermostat

Two-way Voice



AVS for VISTA Control Panels

GSMV – Digital Cellular Communicator

GSMVLP – Internal GSM Radio with Two-way

Voice Support (AVS not needed)

Hardwired to Wireless Conversion

5800C2W – Hardwired to 5800 Wireless Converter

Support & Resources

Dealer Toolkits

Photo Library

Videos

Literature Download Center

MyWebTech

Software

Training

Sales Demo Apps



Honeywell Home

VISTA-128 and VISTA-250 Panels – V-Plex® Expansion

Hardwire Zone Expanders



4208SN Remote Eight-Zone Interface Module



4208SNF Universal Class A and Class B Expander Module



4208U V-Plex Universal Eight-Zone Expander



4209U Four-Zone V-Plex Group Zoning Module



4190SN V-Plex Two-Zone Expander



4193SN V-Plex Two-Zone Expander



4293SN V-Plex Serial Number Interface Module



4297 V-Plex Polling Loop Extender Module

Panel Linking



VA8200 Panel Linking Module

Additional Accessories



AD12612 Auxiliary Power Supply/Battery Charger



ECP-ISO ECP Isolator



4232CBM Connected Building Module