

MANUFACTURED BY: Backyard Discovery 3305 Airport Drive, Pittsburg, KS 66762 800-856-4445

Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476 J.P. Coenstraat 7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 0800-567-8990

ASPEN **Playhouse** Model # 6515B

The assembly manual must be retained since it contains important information



WARNING Adult Assembly Required.

Not suitable for children under two years due to sharp points and small parts. **FOR DOMESTIC USE ONLY. INTENDED FOR OUTDOOR USE.**



Please visit www.backyarddiscovery.com

For the most up to date assembly manual, to register your set, or to order replacement parts Para obtener instrucciones en español, visite www.backyarddiscovery.com



DOWNLOAD THE FREE APP





Made in China

Owner's Manual - Basic Setup Dimensions & Assembly Notes

Place the set on level ground, not less than 6'-7" [2 m] from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.

- While assembling unit, take time before and after each phase to make sure fort is level. If fort is not level, assembly will be difficult and improper assembly may result. Extra care must be taken to insure the fort is square.
- The safe play area refers to a zone extending 6'-7" (2 m) beyond the play product on all sides, including the space above the play product.


SAFE PLAY AREA DIAGRAM


Ground Dimensions

Safe Play Area

6'-6 13/16" [2.0 m] x 4'- 11/16" [1.24 m]

19'-8 13/16" [6.0 m] x 17'-2 11/16" [5.25 m] x 12'- 1/8" [3.7 m]






General Information:

Your set has been designed and engineered for children only and for residential use only. A maximum of 150 lbs. per child is recommended for play activities designed for individual use. A maximum of 120 lbs. per child is recommended for play activities designed for multiple child use. A maximum of 9 children is recommended for this swing set.


WOOD PARTS (NOT TO SCALE)

N1 WINDOW SHELF - W4L17326
N1 WINDOW SHELF - WAL 17326
(x1) 5/8"x2 3/8"x15 3/16" (16x60x386)
N2 WALL TRIM - W4L17327 (x1) 5/8"x2 3/8"x39 3/4" (16x60x1010)
L1 WINDOW - W4L17328
(x1) 5/8"x4 7/16"x17 5/8" (16x112x448)
J1 SHELF SUPPPORT - W4L17329 (x2) 15/16"x2 3/8"x3 1/8" (24x60x80)
(X2) 10/10/X2/0/0 X0/1/0 (24X00X00)
G1 FRONT HEADER - W4L17330 (x1) 15/16"x5 1/4"x44 15/16" (24x134x1142)
(X1) 13/10 X3 1/4 X44 13/10 (24X134X1142)
G2 REAR HEADER - W4L17331 (x1) 15/16"x5 1/4"x44 15/16" (24x134x1142)
(*1) 13/10 23 1/4 244 13/10 (24213421142)
H1 ANGLED HEADER - W4L17332 (x2) 15/16"x3"x40 13/16" (24x76x1036)
J5 SUPPORT BOARD - W4L17333
(x1) 15/16"x2 3/8"x6 11/16" (24x60x170)
NAL FACCIA POARD, INVALATORA
M1 FASCIA BOARD - W4L17334 (x4) 5/8"x3 3/8"x35 3/16" (16x86x894)
0 0
M2 BENCH SEAT - W4L17335
(x2) 5/8"x3 3/8"x19 1/8" (16x86x485)
H3 BENCH UPRIGHT - W4L17336
(x2) 15/16"x3 3/8"x11" (24x86x280)
H4 BENCH SEAT SUPPORT - W4L17337 (x2) 15/16"x3 3/8"x6 9/16" (24x86x166)


WOOD PARTS (NOT TO SCALE)




WOOD PANELS (NOT TO SCALE)




WP1 WALL PANEL - W2A03573 (x1) 3 3/8"x14"x39 3/4" (27x355x1010)



WP2 WALL PANEL - W2A03574 (x1) 3 3/8"x14"x39 3/4" (27x355x1010)




WP3 WALL PANEL - W2A03575 (x1) 1 1/16"x12 3/4"x41 5/8" (27x324x1058)




WP4 WALL PANEL - W2A03576 (x1) 1 1/16"x12 3/4"x41 5/8" (27x324x1058)




WP5 WALL PANEL - W2A03577 (x1) 1 1/4"x15 3/16"x16 1/8" (32x386x410)




WP6 WALL PANEL - W2A03578 (x1) 1 1/4"x15 3/16"x16 1/8" (32x386x410)




WP7 WALL PANEL - W2A03579 (x1) 1 1/4"x16 1/8"x42 7/8" (32x410x1088)



WP8 FENCE PANEL - W2A03584 (x1) 1 1/8"x13"x21 1/16" (28x330x535)




WP9 WALL PANEL - W2A03585 (x1) 1 1/16"x12 3/4"x41 5/8" (27x324x1058)




WP10 WALL PANEL - W2A03586 (x1) 1 1/16"x12 3/4"x41 5/8" (27x324x1058)

WOOD PANELS (NOT TO SCALE)




DP1 BOTTOM DOOR PANEL - W2A03580 (x1) 1 1/16"X15 11/16"X19 11/16" (27x398x500)




DP2 TOP DOOR PANEL - W2A03581 (x1) 1 1/16"x15 11/16"x21 3/8" (27x398x542)




RP1 ROOF PANEL - W2A03583 (x2) 11x17 1/2"x44 3/4" (35x445x1136)



RP2 ROOF PANEL - W2A03587 (x2) 1 3/8"x17 7/8"x44 3/4" (35x454x1136)




J6 INNER CURTAIN ROD HOLDER - W4L17102 (x1) 15/16"x2 3/8"x 2 3/8" (24x60x60)



J7 OUTER CURTAIN ROD HOLDER - W4L17101 (x2) 15/16"x2 3/8"x 2 3/8" (24x60x60)

ACCESSORY COMPONENTS (NOT TO SCALE)





A4M00528 BYD ID TAG (MEDIUM) AGES 2 TO 10 (x1)




A4M00997 METAL CLEAT (x18)



A4M01047 L BRACKET 2.5x38x55x55 (x2)



A4M01846 Z TIE BRACKET (x1)



A6P00020 LATCHING KNOB KIT (x1)



A6P00024 FAUCET KIT (x1)



A100327 HINGE (DOOR, SPRING LOADED) (x2)



A4M00558 HINGE (DOOR, NON-SPRING LOADED) (x2)



A4M01045 BELL ASSEMBLY (x1)




A4M01785 ANGLE BRACKET (x12)



A6P00017 MAILBOX ASSEMBLY (x1)



A6P00023 FLOWER POT HOLDER (x2)



A6P00025 STOVE KIT (x1)

ACCESSORY COMPONENTS (NOT TO SCALE)



A6P00032 SURFACE MOUNT BASIN (x1)




A6P00068 OUTDOOR LIGHT FIXTURE (x2)




A6P00069 FRUIT BASKET KIT (x1)



A4M00527 GROUND STAKE REBAR (x4)



(x2)





A6P00057 PLASTIC CURTAIN ROD (x1)



A6P00553 CURTAIN (x2)

HARDWARE COMPONENTS (NOT TO SCALE)





H100398 | T-NUT BLK

(x4) | 1/4

 \Longrightarrow

H100797 | SCREW PWH BLK

H100392 | SCREW PWH BLK (x82) | 8 x 3/4

H100202 | SCREW PWH BLK

H100408 | SCREW PWH BLK (x2) | 8 x 1/2


(x20) | 8 x 1


(x10) | 8 x 5/8

H100385 | SCREW PFH BLK
(x16) | 8 x 1

H100395 | SCREW PFH BLK
(x10) | 8 x 3/4

H100203 | SCREW PFH BLK (x6) | 8 x 1/2







(x1) | T-30


PRE-ASSEMBLY STEP 1 - SORTING PARTS

It is critical for ease of assembly that you take the time to sort and organize the wood and hardware.

WOOD PARTS:

- Organize wood parts by the three-digit, alpha-numeric number stamped on each board (ex. P01).
- · If there are multiple boards with the same stamped number, stack those pieces together.
- Stamps can be found on the flat surface of the boards or on the end of the boards.
- · Allow yourself plenty of room the wood pieces can take up a significant amount of space.

NOTE: CARTONS ARE NOT ORGANIZED BY BOARD NUMBER.




HARDWARE PARTS:

- We recommend that you have a separate table to organize the hardware.
- Hardware bags are printed with a seven-digit, alpha-numeric part number.
- You can organize your hardware by part number or group by hardware type (i.e. bolts, nuts, etc.).
- · During assembly you only need to reference the last four digits of the number.



PRE-ASSEMBLY STEP 2 - TOOLS REQUIRED



PRE-ASSEMBLY STEP 3 - CHOOSE YOUR ASSEMBLY METHOD

There are several types of assembly instructions available to you.


- 1. Printed Assembly Manual included with your set
- 2. BILT APP 3D interactive instructions
- 3. Combination of the Printed Manual and BILT APP (Note: Step numbers can differ between the two methods)



STEP 1 - PLAYHOUSE ASSEMBLY

QTY PART NUMBER **DESCRIPTION** 16 H100392 SCREW PWH 8x3/4 BLK

WP3 WALL PANEL - W2A03575 (x1) 1 1/16"x12 3/4"x41 5/8" (27x324x1058)



WP4 WALL PANEL - W2A03576 (x1) 1 1/16"x12 3/4"x41 5/8" (27x324x1058)




WP6 WALL PANEL - W2A03578

(x1) 1 1/4"x15 3/16"x16 1/8" (32x386x410)


0

A4M00997 METAL CLEAT (x4)



STEP 2 - PLAYHOUSE ASSEMBLY


	QTY	PART NUMBER	DESCRIPTION
Γ	4	H100385	SCREW PFH 8x1 BLK




WP7 WALL PANEL - W2A03579 (x1) 1 1/4"x16 1/8"x42 7/8" (32x410x1088)

N6 WALL TRIM - W4L17349 (x1) 5/8"x2 3/8"x39 3/4" (16x60x1010)


N2 WALL TRIM - W4L17327 (x1) 5/8"x2 3/8"x39 3/4" (16x60x1010)




STEP 3 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
2	H100202	SCREW PWH 8x5/8 BLK
4	H100797	SCREW PWH 8x1 BLK






STEP 5 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
2	H100202	SCREW PWH 8x5/8 BLK
4	H100797	SCREW PWH 8x1 BLK



STEP 6 - PLAYHOUSE ASSEMBLY


QTY	PART NUMBER	DESCRIPTION
6	H100797	SCREW PWH 8x1 BLK



WP2 WALL PANEL - W2A03574 (x1) 3 3/8"x14"x39 3/4" (27x355x1010)




A4M01785 ANGLE BRACKET (x3)




STEP 7 - PLAYHOUSE ASSEMBLY


8	QTY	PART NUMBER	DESCRIPTION
	6	H100797	SCREW PWH 8x1 BLK




WP1 WALL PANEL - W2A03573 (x1) 3 3/8"x14"x39 3/4" (27x355x1010)




A4M01785 ANGLE BRACKET (x3)



STEP 8 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
8	H100392	SCREW PWH 8x3/4 BLK




STEP 9 - PLAYHOUSE ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
16	H100392	SCREW PWH 8x3/4 BLK

H1 ANGLED HEADER - W4L17332 (x2) 15/16"x3"x40 13/16" (24x76x1036)

A4M00997 METAL CLEAT (x4)




STEP 10A - PLAYHOUSE ASSEMBLY




QTY | PART NUMBER | DESCRIPTION H100201 SCREW PFH 8x2 1/2 BLK


G1 FRONT HEADER - W4L17330 (x1) 15/16"x5 1/4"x44 15/16" (24x134x1142)



STEP 10B - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
8	H100392	SCREW PWH 8x3/4 BLK



STEP 11 - PLAYHOUSE ASSEMBLY

QTYPART NUMBERDESCRIPTION4H100201SCREW PFH 8x2 1/2 BLK

G2 REAR HEADER - W4L17331 (x1) 15/16"x5 1/4"x44 15/16" (24x134x1142)



STEP 12A - PLAYHOUSE ASSEMBLY


QTY	PART NUMBER	DESCRIPTION
2	H100382	SCREW PFH 8x1 3/4 BLK

0


M4 BACK UPRIGHT - W4L17350 (x1) 5/8"x3 3/8"x26" (16x86x660)




G3 SHELF SUPPORT - W4L17342 (x1) 15/16"x5 1/4"x5 7/8" (24x134x150)



STEP 12B - PLAYHOUSE ASSEMBLY



	QTY	PART NUMBER	DESCRIPTION
	2	H100202	SCREW PWH 8x5/8 BLK
[2	H100392	SCREW PWH 8x3/4 BLK



STEP 13 - PLAYHOUSE ASSEMBLY


QTYPART NUMBERDESCRIPTION4H100380SCREW PFH 8x1 1/8 BLK

9 6

J4 SUPPORT BOARD - W4L17346 (x1) 15/16"x2 3/8"x6 11/16" (24x60x170)


• •


J5 SUPPORT BOARD - W4L17333 (x1) 15/16"x2 3/8"x6 11/16" (24x60x170)



STEP 14 - PLAYHOUSE ASSEMBLY

QTY PART NUMBER **DESCRIPTION** H100387 SCREW PFH 8x1 1/4 BLK






STEP 15 - PLAYHOUSE ASSEMBLY

N1 WINDOW SHELF - W4L17326 (x1) 5/8"x2 3/8"x15 3/16" (16x60x386)

QTY	PART NUMBER	DESCRIPTION
3	H100387	SCREW PFH 8x1 1/4 BLK




STEP 16 - PLAYHOUSE ASSEMBLY


Q	TY	PART NUMBER	DESCRIPTION
4		H100382	SCREW PFH 8x1 3/4 BLK
5		H100387	SCREW PFH 8x1 1/4 BLK



L1 WINDOW - W4L17328 (x1) 5/8"x4 7/16"x17 5/8" (16x112x448)




J1 SHELF SUPPPORT - W4L17329 (x2) 15/16"x2 3/8"x3 1/8" (24x60x80)



STEP 17 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
8	H100387	SCREW PFH 8x1 1/4 BLK



STEP 18 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
2	H100202	SCREW PWH 8x5/8 BLK



STEP 19 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
4	H100387	SCREW PFH 8x1 1/4 BLK



STEP 20 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
2	H100200	SCREW PFH 8x1 1/2 BLK




STEP 21 - PLAYHOUSE ASSEMBLY




A6P00032 SURFACE MOUNT BASIN (x1)


QTY	PART NUMBER	DESCRIPTION
2	H100202	SCREW PWH 8x5/8 BLK



STEP 22 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
4	H100380	SCREW PFH 8x1 1/8 BLK




STEP 23 - PLAYHOUSE ASSEMBLY



A6P00069	FRUIT BASKET KIT
(x1)	

QTY	PART NUMBER	DESCRIPTION
6	H100203	SCREW PFH 8x1/2 BLK




STEP 24 - PLAYHOUSE ASSEMBLY



N5 DOOR STOP - W4L17348 (x1) 5/8"x2 3/8"x3 3/8" (16x60x86)

QTY	PART NUMBER	DESCRIPTION
3	H100387	SCREW PFH 8x1 1/4 BLK



STEP 25A - PLAYHOUSE ASSEMBLY

	QTY	PART NUMBER	DESCRIPTION
Y	12	H100804	T-NUT 8/32
	12	H100806	SCREW POH-MS 8/32x1 1/8" BLK



DP1 BOTTOM DOOR PANEL - W2A03580 (x1) 1 1/16"X15 11/16"X19 11/16" (27x398x500)




A100327 HINGE (DOOR, (x2) SPRING LOADED)




DP2 TOP DOOR PANEL - W2A03581 (x1) 1/16"x15 11/16"x21 3/8" (27x398x542)




A4M00558 HINGE (DOOR, (x2) NON-SPRING LOADED)




STEP 25B - PLAYHOUSE ASSEMBLY








STEP 26 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
6	H100804	T-NUT 8/32
6	H100806	SCREW POH-MS 8/32x1 1/8" BLK




STEP 27 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
6	H100804	T-NUT 8/32
6	H100806	SCREW POH-MS 8/32x1 1/8" BLK



STEP 28 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
4	H100392	SCREW PWH 8x3/4 BLK



STEP 29 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
4	H100392	SCREW PWH 8x3/4 BLK



STEP 30A - PLAYHOUSE ASSEMBLY


QTY	PART NUMBER	DESCRIPTION
8	H100385	SCREW PFH 8x1 BLK

M5 GABLE TRIM - W4L17354 (x2) 5/8"x3 3/8"x30 1/2" (16x86x774) M6 GABLE TRIM - W4L17355 (x2) 5/8"x3 3/8"x30 1/2" (16x86x774)

K903 GABLE BOARD - W4L17353 (x2) 7/16"x3 3/8"x17 11/16" (11x86x450)

K901 GABLE BOARD - W4L17351 (x2) 7/16"x3 3/8"x43 1/8" (11x86x1095)


COMPLETE THIS STEP TWICE




0 ...

STEP 30B - PLAYHOUSE ASSEMBLY


QTY	PART NUMBER	DESCRIPTION
4	H100385	SCREW PFH 8x1 BLK
10	H100395	SCREW PFH 8x3/4 BLK










STEP 31A - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
8	H100392	SCREW PWH 8x3/4 BLK










STEP 32 - PLAYHOUSE ASSEMBLY

·	
1	[1
1	
i	
,	<u> </u>
l	
i e	

QTY	PART NUMBER	DESCRIPTION
8	H100200	SCREW PFH 8x1 1/2 BLK

RP1 ROOF PANEL - W2A03583 (x2) 11x17 1/2"x44 3/4" (35x445x1136)




STEP 33 - PLAYHOUSE ASSEMBLY

	,
	•
	,
	,
<u> </u>	
	,
ř.	,

QTY	PART NUMBER	DESCRIPTION
8	H100200	SCREW PFH 8x1 1/2 BLK


RP2 ROOF PANEL - W2A03587 (x2) 1 3/8"x17 7/8"x44 3/4" (35x454x1136)




STEP 34 - PLAYHOUSE ASSEMBLY

M1 FASCIA BOARD - W4L17334 (x4) 5/8"x3 3/8"x35 3/16" (16x86x894)

QTY	PART NUMBER	DESCRIPTION
16	H100200	SCREW PFH 8x1 1/2 BLK




STEP 35 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
4	H100200	SCREW PFH 8x1 1/2 BLK
4	H100387	SCREW PFH 8x1 1/4 BLK

.

P01 FENCE POST - W4L17339 (x1) 1 7/16"1 7/16"19" (36x36x483)




STEP 36 - PLAYHOUSE ASSEMBLY




QTY	PART NUMBER	DESCRIPTION
1	H100200	SCREW PFH 8x1 1/2 BLK

ON THE SIDE OF THE MAILBOX BODY.



53

STEP 37 - BENCH ASSEMBLY




J2 BENCH GROUND BOARD - W4L17338 (x1) 15/16"x2 3/8"x13 3/16" (24x60x335)

QTY	PART NUMBER	DESCRIPTION
2	H100171	BOLT WH 1/4x1 BLK
2	H100398	TNUT-1/4" BLK



A4M01047 L BRACKET 2.5x38x55x55 (x2)




STEP 38 - BENCH ASSEMBLY

0	0	0	0
0	0	۰	0

H3 BENCH UPRIGHT - W4L17336 (x2) 15/16"x3 3/8"x11" (24x86x280)

QTY	PART NUMBER	DESCRIPTION
8	H100382	SCREW PFH 8x1 3/4 BLK




STEP 39 - BENCH ASSEMBLY



H4 BENCH SEAT SUPPORT - W4L17337 (x2) 15/16"x3 3/8"x6 9/16" (24x86x166)

	QTY	PART NUMBER	DESCRIPTION
[3	H100382	SCREW PFH 8x1 3/4 BLK




STEP 40 - BENCH ASSEMBLY

0 0

QTYPART NUMBERDESCRIPTION8H100382SCREW PFH 8x1 3/4 BLK


M2 BENCH SEAT - W4L17335 (x2) 5/8"x3 3/8"x19 1/8" (16x86x485)



STEP 41 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
2	H100397	BOLT WH 1/4x1 1/4 BLK
2	H100398	TNUT-1/4" BLK




STEP 42 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
2	H100408	SCREW PWH 8x1/2 BLK

A4M00528 BYD ID TAG (MEDIUM) AGES 2 TO 10 (x1)



STEP 43 - PLAYHOUSE ASSEMBLY



QTY	PART NUMBER	DESCRIPTION
4	H100379	T-NUT 5/16 BLK
4	H100459	BOLT WH 5/16x1 1/4 BLK

