












ASSEMBLY INSTRUCTION

ITEM: 6820-10462-80 Executive Desk
6820-10462-85 Executive Desk
6820-10462-99 Executive Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



| HARDWARE PACK | | | | |
|---------------|---|--------------|-----------|------|
| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
| A |  | Allen Wrench | 73*29*5mm | 1 PC |

| PARTS LIST | | | | |
|------------|--|---------------------|------|------|
| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
| 1 |  | Left Pedestal | | 1 PC |
| 2 |  | Center Back Panel | | 1 PC |
| 3 |  | Right Pedestal | | 1 PC |
| 4 |  | Left Top Drawer | | 1 PC |
| 5 |  | Keyboard Drawer | | 1 PC |
| 6 |  | Right Top Drawer | | 1 PC |
| 7 |  | Left Middle Drawer | | 1 PC |
| 8 |  | Right Middle Drawer | | 1 PC |
| 9 |  | Top Frame | | 1 PC |




ITEM: 6820-10462-80 Executive Desk
6820-10462-85 Executive Desk
6820-10462-99 Executive Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
Read all instruction and study the drawing carefully before starting the assembly process.



Adjust Leveler if needed
to level Desk on uneven floor.




The adjustable shelves are
screwed in place to avoid
damage during transit.
To adjust the shelf height,
remove screws then place
shelf pins in the desired level.

ITEM: 6820-10462-80 Executive Desk
6820-10462-85 Executive Desk
6820-10462-99 Executive Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.




STEP 1:

Loosen bolts (B), lock washers (C) and flat washer (D) by using Allen wrench (A), then remove Top Frame (9) from left and right pedestal (1 & 3).

ITEM: 6820-10462-80 Executive Desk
6820-10462-85 Executive Desk
6820-10462-99 Executive Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 2:

Loosen bolts (B), lock washers (C) and flat washer (E) by using Allen wrench (A), then remove center back panel (2) from left and right pedestal (1 & 3).