

USER'S MANUAL

BRT27A

27" AMPLIFIED SOUND BAR FEATURES BUILT-IN **CLASS D** (DIGITAL) AMPLIFIER AND BUILT-IN RGB ILLUMINATION



3451 Lunar Court • Oxnard, CA 93030

Tech Support: www.bossaudio.com/support/technical-support



l rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, includ pying, recording, or other electronic or mechanical methods, without the prior written permission of BOSS AUDIO Inc

Copyright © 2016 BOSS AUDIO In 418 VER:1.0 EN



Thank you for purchasing this

3077

BRT27A Soundbar Sound System Please read through these instructions carefully so you will know how to operate your model properly. After you have finished reading the instructions, keep this document in a safe place for future reference.

THIS PACKAGE CONTAINS

1 - BRT27A Soundbar Speaker System

1 - RF RGB LED Remote w/ CR2032 Battery



1 - Quick Connect Power Cable



1 - User Manual Quick Start Guide / Poster


1 - Warranty Card / Facebook Card

Bluetooth*

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license. Other trademarks and trade names are those of their respective owners.

INFORMATION TO THE USER

BLUETOOTH OPERATION



PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

1) Power on the *BRT27A* by short-pressing the 6 Power button, long-press the 4

Bluetooth button for 3 seconds, the BLUE LED will start to rapidly flash, signaling that the **UNIT** is now ready for **Bluetooth** pairing

NOTE: You have 2 minutes before you must restart this procedure over again.

2) The **BRT27A** is now in pairing mode:


- a. Go into the **Settings Menu** of your device
- b. Enter the Bluetooth Menu
- c. TURN ON Bluetooth and press SCAN d. "Boss audio BRT27A" will now be displayed under AVAILABLE DEVICES
- e. If prompted, enter passcode: "0000"

- a. Go into the Settings Menu of your iOS device
- b. Enter the Bluetooth Menu c. TURN ON Bluetooth
- d. "Boss audio BRT27A" will now be displayed e. If prompted, enter passcode: "0000"

3) If Boss audio BRT27A is not seen, repeat the above steps to refresh the "Device List"

4) When the connection is successful a tone will be heard, and the Bluetooth LED indicator will light solid, you are now ready to stream music from your favorite media player to the UNIT

BEFORE YOU START INSTALLATION



To avoid potential shorts in the electrical system, be sure to disconnect the (–) battery cable before installation. Use this unit with a 12-Volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.



When replacing the fuse, be sure to only use a fuse of the rating specified on this product. To avoid short-circuiting, cover any disconnected leads with insulating tape. It is especially important to insulate any unused wires, which if left uncovered may cause a short circuit. When connecting other devices to this product, refer to the manual for the product to be connected. The black cable is ground, make sure to connect the ground wire first. Ensure that the ground wire is properly connected to metal parts of the vehicles body frame or direct to the battery if your vehicle does not have a grounded chassis frame. The ground wire of this units power amp and a second powered system must be connected to the frame separately with different screws. If the screw for the ground wire loosens or falls out, it could result in fire or malfunction.

GETTING STARTED



1) Press the RGB ILLUMINATION ON/OFF - Once to Turn ON RGB Mode, again to Turn OFF RGB Mode or press the POWER Button on the RGB CONTROLLER to POWER ON/OFF RGB Mode

2) The RGB ILLMINATION ON/OFF is synchronized with the BRT27A RGB RF CONTROLLER 3) Auto 10 minute timer when BRT27A ACC is turned OFF: RGB ILLUMINATION ON/OFF and BRT27A RGB RF CONTROLLER can be turned on respectively.

NOTE!! To conserver battery life, the RGB ILLUMINATION will automatically turn off after 10 minutes when BRT27A ACC is turned OFF

INFORMATION TO THE USER

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of this device.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter. The Bluetooth antenna cannot be removed (or replaced) by user. This equipment complies with FCC/ IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without maximum permissive exposure (MPE) evaluation. But it is desirable that it should be installed and operated keeping the radiator at least 20 cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles). Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

□ Relocate or reorient the receiving antenna.


□ Increase the separation between the equipment and receiver. □ Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected. □ Consult the dealer or an experienced radio/TV technician for help.

CAUTION!!

ADJUSTMENT OR ALTERATIONS OF THIS DEVICE MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

BLUETOOTH OPERATION



RECONNECTION

1) Power on the BRT27A and your last paired Bluetooth device.

2) Ensure you are within range of the UNIT, the unit will now automatically reconnect

3) If the device is out of range from the **UNIT**, it will disconnect automatically: a. The UNIT will reconnect automatically to your device when in range

- 4) If your device was previously paired with the UNIT a. Ensure no other devices are currently paired
 - b. Enter the Bluetooth Menu on your device being paired
 - C. "Boss audio BRT27A" will display under AVAILABLE DEVICES d. Choose the "Boss audio BRT27A" to reconnect


5) To clear all previously paired devices from memory, press and hold the *Bluetooth* button for 10 seconds

NOTE: Some devices may require a manual Bluetooth reconnection once the Bluetooth devices are powered OFF / ON and/or back in range, repress the "Boss audio BRT27A" button in BLUETOOTH settings on your device


Using this product without running the engine can drain the battery. To avoid battery exhaustion, be sure to occasionally run the

MOUNTING THE SOUNDBAR

vehicles engine while using this product.



BRACKETS RUBBER BUSHINGS



Some applications may require optional friction tape between rubber bushings for a secure, tight fit, this can be found at most local hardware stores

1) Determine the size of rollbar for your vehicle, install rubber bushings on rollbar 2) Insert and align notch of rubber bushings into the aluminum brackets 3) Apply supplied Loctite to allen bolt tips, then align the allen bolts and T-nuts into the T-channel, firmly tighten. Let dry for 20 minutes. Fully cures in 24 hours. 4) Recheck all allen bolts are tight, ensure T-nut's are properly seated in the T-channel correctly

CAUTION!!

Mounting brackets should be periodically checked to be sure they are tight and secure before use of the vehicle.

BEFORE YOU START

IMPORTANT SAFETY PRECAUTIONS

■ Do not operate mobile equipment while driving a motorized vehicle – safe driving and safety consideration of others should always be your highest priority ■ In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized BOSS AUDIO SYSTEMS Service Center Using this product in this condition may result in permanent damage to the system

■ Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion, or ear discomfort

■ BE SURE TO OBSERVE THE FOLLOWING GUIDELINES:

- Use caution or temporarily discontinue use in potentially hazardous situations

- Do not turn up the volume so high that you can't hear what's around you

INSTALLATION PRECAUTIONS

WARNING - Always consult a professional installer ■ Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without professional training and experience in electronic equipment

and motorized vehicle accessories may be dangerous and could expose you to the risk of

electric shock, injury or other hazards ■ Refer any repairs to a qualified **BOSS AUDIO SYSTEMS** Service Center ■ The **BRT27A** should be hard wired directly to the main vehicle battery

■ When wiring directly to the vehicles battery, be sure to disconnect the battery's negative terminal wire before starting any wiring procedures ■ The ground cable length should be as short as possible (See wiring diagram)

■ The **BRT27A** has a weather resistant design, it should not be under any circumstances

submerged in, or under water ■ Use only the supplied installation parts provided with the BRT27A

■ Wash with a mild detergent and lukewarm water using a clean sponge or a soft cloth Rinse well with clean water


"DO NOT'S" - Very Important DON'T clean in hot sun or on very hot days

■ DON'T use abrasive or highly alkaline cleaners on the main body ■ DON'T scrape the main body with razor blades, or other sharp instruments

■ DON'T ever use, gasoline, acetone or carbon tetrachloride ■ DON'T ever use a pressure washer aimed at the speakers

CAUTION!! Using other mounting methods may void this warranty

STREAMING MUSIC



MULTIFUNCTION CONTROLLER BLUETOOTH OPERATION

1) Press the **7 PLAY/PAUSE** once to start playing music or press the **PLAY** button from

2) To skip songs or advance, press the 2 NEXT TRACK button

3) To select the previous song, press the 1 PREVIOUS TRACK button


VOLUME CONTROL

4) To raise the volume long-press the **2 NEXT TRACK** button or use your devices controls 5) To lower the volume long-press the (1) **PREVIOUS TRACK** button or use your devices controls

NOTE: If BLUETOOTH or AUX is disconnected for more than 10 minutes the UNIT will automatically turn OFF, however, when not in use the ACC switch should be manually turned **OFF** to keep the vehicles main battery from draining

Make sure your Bluetooth device volume is set at 100% level before stowing your device

GETTING STARTED (RF CONTROLLER)



USING THE REMOTE CONTROL

 When use for the first time, pull out the film protruding the tray RF controller range: Up to 25ft (LoS) Do not obstruct the RF remote with metal Always keep away from small children · Do not store in direct sunlight · Do not submerge in mud and/or water

> Slide the tray out on back of the remote control and insert battery with the (+) and minus (-) poles pointing in the proper direction

(A) RF CONTROLLER POWER ON / OFF

SPEED UP

COLOR DOWN

TOOLS NEEDED:

- Wrench or Pliers

- 3mm Allen Wrench

- Crimp Tool


MODE UP AUTO DEMO (LONG PRESS FOR SINGLE COLOR MODE)

BRIGHTNESS UP BRIGHTNESS DOWN MODE DOWN

9) COLOR UP (10) SPEED DOWN

> **OPTIONAL TOOLS NEEDED:** Hand saw or Jigsaw

GETTING STARTED GETTING TO KNOW YOUR



(A) OCP - ONBOARD CONTROL PANEL

PREVIOUS TRACK-Short Press:

Long press and hold for VOLUME - Ramp DOWN **NEXT TRACK-Short Press**;

Long press and hold for VOLUME - Ramp UP RGB ILLUMINATION ON/OFF - (Auto 10 minute timer when BRT27A

BLUETOOTH PAIRING INDICATOR LED - BLUE / AUX RED COLOR

EQ - EQ1 | EQ2 | EQ3 | FLAT - EQ1 Default Press and hold for 3 seconds POWER ON - Short Press;

RESET- Press and hold for 10 seconds 7 PLAY/PAUSE - AUX MUTE

ACC is turned OFF;)

AUX-INPUT



MULTIFUNCTION CONTROLLER AUX-IN OPERATION

1) Power on the *OCP* by short-press the **6 POWER** button 2) Disconnect any paired *Bluetooth* device by turning off *Bluetooth* in your devices 3) Connect your 3.5mm AUX-IN cable located on right side of the BRT27A to your devices 4) Route the wire back to BRT27A, secure your device in a safe location

VOLUME CONTROL 5) To raise the volume long- press the **2 NEXT TRACK** button on the OCP 6) To lower the volume long- press the (1) **PREVIOUS TRACK** button on the OCP 7) To **MUTE** the volume press the **7 PLAY/PAUSE** button

Make sure your device headphone volume is set at 100% level before stowing your device

WIRE DIAGRAM

12) **BOSS REFLEX SERIES** DAISY CHAIN BATTERY

> Range: 33ft (10m) Class 2 • Dimension: 3.0" Cone Type: PP CARBON Tweeter Size: 1" SOFT DOME

• Maximum Output Power: 500 Watts

Color: Black Powder Coating

 Operational Power: 14.4VDC (10-16V allowable MAX Current Draw: 11.7A Replacement Fuse: 15A ATO TYPE Cabinet Material: Aluminum Extrusio SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

Weight: 16.53lbs / 7.50kg
Dimensions Inches WxHxD: 27.00 x 4.98 x 5.55 • Dimensions cm WxHxD: 68.6 x 12.6 x 14.1 • Storage Temperature: 5°F to 175°F / -15°C to 80°C Operation Temperature: 32°F to 140°F / 0°C to 60°C

Input Impedance: 10kΩ
Frequency Response: 45Hz-25kHz **REPLACEMENT BATTERY - CR2032**

SPECIFICATIONS BLUETOOTH · Version: 4.1 A2DP / AVRCP / GATT

20-Band DSP: 4 Preset EQ
 RCA Line Output: 2V RMS