

Item No:TD-12681B

Teamson Kids - Little Chef Berlin Modern Play Kitchen - White / Blue

WARNING

Small parts and sharp points may be present prior to assembly.


Care Instructions

To clean your product, use mild soap and water on adamp cloth. Do not use window cleaners or cleaning abrasives as they will scratch the surface and could damage the protective coating.

Customer Service

For questions regarding this product, or to recevice replacement or missing parts, please contact customer service based on your location. Please have ready the model number and part number(s) located in this assembly instruction sheet when you contact us.

www.teamsonkids.com



PRODUCT PARTS:					
Α	В	С	D	Е	F
1PC	1PC	1PC	1PC	1PC	1PC
G	Н	l	J	K	L
1PC	1PC	1PC	1PC	1PC	1PC
M	N	0	Р	Q	R
	000				
1PC	1PC	3PCS	1PC	1PC	1PC
S	Т	U	V	W	
1PC	1PC	1PC	1PC	1PC	

HARDWARE:

1	2	3	4	(5)	6
Ø3*9mm		(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	3		
16PCS	4PCS	46PCS	3PCS	1PC	1PC
7	8	9	10	11)	12
	()))))))))))))))))))))))))))))))))))))		Ø5*30mm	⊕‱‱ Ø4*35mm	%)))))) Ø2.5*8mm
1PC	1PC	4PCS	10PCS	4PCS	18PCS
12	13	14)			

1PC

STEP 1


1PC


1	Ø3*9mm	2PCS	3	⊕aaaaaaaa Ø4*22mm	2PCS
<u>(2)</u>	S	1PC	<u>(4)</u>		1PC


1PC


STEP 2


1	•	2PCS	3	accacacaca()	2PCS
	Ø3*9mm			Ø4*22mm	
2		1PC	4	8	1PC































STEP 24

