



Quantum REL30 Part List

Key No.	Description	Part No. REL30XPT	Q'TY	Key No.	Description	Part No. REL30XPT	Q'TY
1	Drag Knob Assembly	CAK332-01	1	25	Line Roller Washer	EAK102-51	1
2	Spool Kit Include	AAK421-01	1	26	Line Roller	CAK004-01	1
	2A - Retaining Ring	EAK172-01	1	27	Bushing	EAK016-01	2
	2B - Drag Washer "D"	CAK080-01	2	28	Line Roller Washer	EAK102-52	1
	2C - Drag Washer "A"	CAK081-01	2	29	Bail Wire Assembly	AAK347-01	1
	2D - Drag Washer "B"	CAK033-01	3	30	Rotor Adjust Washer	CAK065-01	1
	2E - Bushing	CAK058-01	1	31	Pinion Ball Bearing Holder Screw	CAK051-01	3
	2F - Spool Assembly	AAK321-01	1	32	Pinion Ball Bearing Holder Unit	AAK322-01	1
	2G - Clicker Holder	EAK204-01	1	33	Pinion Ball Bearing Holder Seal	AAK263-01	1
	2H - Clicker	EAK103-01	1	34	Pinion Ball Bearing	TW058-10	4
	2I - Clicker Spring	EAK068-01	1	35	Pinion Ball Bearing Retainer	AAK040-01	1
	2J - Clicker Spring Screw	EAK114-01	1	36	Clutch Unit	AAK463-01	1
	2K - Clicker Screw	EAK246-01	1	37	Washer	CAK110-01	1
	2L - Line Clip Spring	AAK049-01	1	38	Pinion	AAK011-01	1
	2M - Line Clip	CAK128-01	1	39	Trip Bumper Screw	EAK123-01	1
	2N - Line Clip Screw	EAK114-01	1	40	Rotor Brake Screw	EAK135-01	1
3	Retainer Ring	EAK038-01	1	41	Trip Bumper	AAK119-01	1
4	Spool Ball Bearing	CH027-08	1	42	Rotor Brake	AAK145-01	1
5	Seal	CAK251-01	1	43	Handle Screw Cap	CAK073-01	1
6	Spool Adjust Washer	CAK030-01	1	44	Handle Screw Cap Seal	CAK266-01	1
7	Main Shaft Assembly	AAK315-01	1	45	Body	AAK001-01	1
8	Rotor Nut Retainer Screw	EAK094-01	3	46	Side Cover Seal	AAK254-01	1
9	Rotor Nut Retainer	EAK118-01	1	47	Drive Gear	AAK012-01	1
10	Rotor Nut Retainer Seal	CAK265-01	1	48	Drive Gear Ball Bearing Seal Plate	AAK255-01	2
11	Rotor Nut	CAK006-01	1	49	Drive Gear Ball Bearing Seal	AAK262-01	2
12	Rotor Seal	EAK264-01	1	50	Drive Gear Ball Bearing Screw	EAK220-01	6
13	Arm Lever Screw	AAK225-01	2	51	Side Cover	AAK023-01	1
14	Bushing	AAK259-01	2	52	Side Cover Screw	AAK057-02	1
15	Bail Holder	AAK017-01	1	53	Side Cover Screw	AAK057-01	2
16	Rotor	AAK009-01	1	54	O/S Gear Assembly	AAK353-01	1
17	Kick Lever	AAK019-01	1	55	O/S Gear Screw	CAK111-01	1
18	Cam	AAK031-01	1	56	O/S Slider	AAK025-01	1
19	Coil Spring	AAK022-01	1	57	Main Shaft Screw	AAK100-01	1
20	Rotor Cover	AAK087-01	1	58	Guide Pin	AAK211-01	1
21	Rotor Cover Screw	AAK077-01	1	59	O/S Slider Plate	AAK084-01	1
22	Line Roller Screw	EAK108-01	1	60	O/S Slider Plate Screw	EAK085-01	1
23	Arm Lever	AAK007-01	1	61	Handle Assembly	AAK318-01	1
24	Line Roller Collar	AAK102-01	1				