



avanti.

Bullet Ice Maker Quick Start Guide

Getting Started:

1. Make certain that the **Drain Plug** underneath the unit is closed.
2. **Plug** the ice maker into the wall outlet.
3. **Open the lid** and remove the ice basket.
4. **Fill** the water reservoir to the max water level mark.
5. **Reinsert** ice basket and close the lid.
6. Press the **POWER** button.
7. Press the **SELECT** button, to change between either the small or large ice size.
8. Fresh ice cubes will automatically dispense into the basket.



Drain Plug

Button Reference

Power	Full Ice	Add Water	Small Ice	Large Ice	Cleaning	Select

Quick Info:

Ice Full LED Light: will light up when the ice basket is full and the ice maker will automatically stop the ice making cycle.

- When ice is removed from the ice basket, the ice maker will restart its ice making function automatically.

Add Water LED Light: will light up when the water reservoir is empty, the ice making cycle will stop automatically.

Do not tilt the ice maker more than 45° during transport or use. Avoid turning it upside down, as this could damage the compressor or refrigeration system. Allow the fluids in the compressor to settle for 2 hours after moving or transporting the ice maker before using it.

To Refill:

Open the lid and remove the ice basket.



1. **Fill** the water reservoir to the max water level mark.
2. Press the **POWER** button.
3. Press the **SELECT** button, to change between either the small or large ice size.

avanti.

Guía De Inicio Rápido De La Máqui

Para empezar:

1. Asegúrese de que el **tapón de drenaje** debajo de la unidad esté cerrado.
2. **Enchufe** la máquina de hielo en el tomacorriente.
3. **Abra la tapa** y retire la cesta de hielo.
4. **Llene** el depósito de agua hasta la marca de nivel máximo de agua.
5. **Vuelva a colocar** la cesta de hielo y cierre la tapa.
6. Presione el botón **ENERGÍA**.
7. Presione el botón **SELECCIONAR** para cambiar entre el tamaño de hielo pequeño o grande.
8. Los cubitos de hielo frescos se dispensarán automáticamente en la canasta.



Tapón De Drenaje

Referencia del botón

						
Energía	Llena De Hielo	Agregar Agua	Hielo Pequeño	Hielo Grande	Limpieza	Seleccionar

Información rápida:

Luz LED "Llena de hielo": se iluminará cuando la cesta de hielo esté llena y el ciclo de fabricación de hielo se detendrá automáticamente.

- Cuando se retira el hielo de la cesta de hielo, la máquina de hielo reiniciará su función de fabricación de hielo automáticamente.

Luz LED "Agregar agua": se iluminará cuando el depósito de agua esté vacío, el ciclo de fabricación de hielo se detendrá automáticamente.

No incline la máquina de hacer hielo más de 45° durante el transporte o el uso. Evite darla vuelta, ya que esto podría dañar el compresor o el sistema de refrigeración. Deje que los líquidos en el compresor se asienten durante 2 horas después de mover o transportar la máquina de hacer hielo antes de usarla.

Para rellenar:

Abra la tapa y retire la cesta de hielo.

1. **Llene** el depósito de agua hasta la marca de nivel máximo de agua.
2. Presione el botón **ENERGÍA**.
3. Presione el botón **SELECCIONAR** para cambiar entre el tamaño de hielo pequeño o grande.