


ITEM# 87232









Black/Cherry 36" H, 46" W Corner Console

Leick
Home
SINCE 1910

2219 S. 19th St.
Sheboygan, WI 53081
Ph: 920-451-4060
Fax: 920-451-4063
info@leickfurnituresince1910.com



Hardware List





Item	Description	Qty
a	 Bolt 1/4" * 1-1/8"	8PCS
b	 Allen wrench	1PC
c	 Washer 1/4" * 12mm	8PCS
d	 Shelf metal clip	12PCS
e	 Door Pull	1PC
f	 Machine screw for door pull 5/32" * 3/4"	1PC
g	 Drawer Pull	1PC
h	 Machine screw for Drawer pull 5/32" * 3/8"	2PCS

Parts List

Item	Description	Qty
A	Cabinet	1PC
B	Top Panel	1PC
C	Bottom Panel	1PC
D	Adjustable Shelf	3PCS
E	Left Wood Support	1PC
F	Right Wood Support	1PC

Assembly Instructions

Two person assembly recommended.

<p>step 1 Unfold Cabinet.</p> 	<p>step 2 Bolt on Wood Support with 4 bolts.</p> 
<p>step 3 Insert bottom panel.</p> 	<p>step 4 Bolt on top with 4 bolts and install door pull. DO NOT OVER TIGHTEN.</p> 
<p>step 5 Install shelf clips and insert shelves.</p> 