

ITEM# 82360

Mission 25"H, 60"W TV Console

Leick
Home
SINCE 1910

2219 S. 19th St.


Sheboygan, WI 53081

Ph: 920-451-4060








Fax: 920-451-4063

info@leickhome.com

www.leickhome.com



Hardware List






Item	Description	Qty
a	 Bolt 1/4"x1-1/8"	6PCS
b	 Allen wrench	1PC
c	 Washer 1/4"x12mm	6PCS
d	 Flat Shelf Supports	12PCS
e	 Door Pull	4PCS
f	 Machine screw for door pull 5/32"x3/4"	8PCS
g	 Rounded Shelf Supports	8PCS

Parts List

Item	Description	Qty
A	Cabinet	1PC
B	Top Panel	1PC
C	Side Panel	2PCS
D	Middle Bottom Panel	1PC
E	Side Bottom Panel	2PCS
F	Middle Adjustable Shelf	1PC
G	Side Adjustable Shelf	2PCS

Assembly Instructions

Two person assembly recommended.

<p>Step 1 Pull the face frame to unfold the cabinet.</p> 	<p>Step 2 Open 4 doors. Screw-in eight rounded shelf supports onto vertical panels, then insert the bottom panels.</p> 
<p>Step 3 Insert two side panels.</p> 	<p>Step 4 Put the top panel on and fasten with 6 bolts. DO NOT OVER TIGHTEN.</p> 
<p>Step 5 Install flat shelf supports and insert shelves.</p> 	<p>Step 6 Install door pulls.</p> 