

LIMITED WARRANTY STATEMENT

The manufacturer warranties safe operation and reliability only under the following conditions:

- The product is installed and operated according to the assembly and operating instructions.
- Only original replacement parts are used.

General Terms

This Limited Warranty applies to the enclosed product (the "Product") distributed by Great American Duck Races, Inc., an Arizona corporation (doing business as Great American Marketing and Events) ("GAME").

- GAME warrants that the Product will be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of purchase. (Your dated sales or delivery receipt, showing the date of your Product purchase, is your proof of the purchase date.) During the warranty period, GAME will repair or replace any defective parts at no charge.
- All defective parts that are replaced by GAME will be replaced, at GAME's discretion, with either new parts or used parts that meet or exceed performance specifications for new parts. All parts removed from the Product under this warranty will become the property of GAME. Repair or replacement of any parts will not serve to extend the ninety (90) days warranty period.
- This Limited Warranty does not apply to expendable parts. This Limited Warranty does not extend to any product (a) from which the serial number has been removed or (b) that has been damaged or rendered defective (i) as a result of accident, misuse, abuse or other external causes; (ii) by operation outside the usage parameters stated in the manual that shipped with the Product; (iii) by the use of parts not manufactured or sold by GAME; or (iv) by modification or service by anyone other than GAME or an authorized GAME distributor.
- If a defect is identified within the warranty period, please contact GAME.

EXCEPT FOR THE LIMITED WARRANTY SET FORTH ABOVE, GAME EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR STATUTORY (INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE). ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THE ABOVE LIMITED WARRANTY.

Limitation of Liability

EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE, IN NO EVENT WILL GAME HAVE ANY LIABILITY OF ANY KIND WHATSOEVER (WHETHER UNDER CONTRACT, TORT, OR ANY OTHER THEORY OF LEGAL LIABILITY) TO ANY PERSON WITH RESPECT TO THE PRODUCT (INCLUDING, WITHOUT LIMITATION, (A) ANY USE OR MISUSE OF THE PRODUCT, (B) ANY FAILURE OR MALFUNCTION OF THE PRODUCT, (C) ANY BODILY INJURY, DEATH, LOSS OF OR DAMAGE TO ANY PROPERTY, OR ANY OTHER DAMAGES RELATED TO OR RESULTING FROM THE PRODUCT OR ITS USE (INCLUDING, WITHOUT LIMITATION, ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, LOST PROFITS, LOSS OF USE), EVEN IF GAME OR GAME'S AUTHORIZED REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF ANY SUCH DAMAGES.

Severability

Any provision of this Limited Warranty which is prohibited or unenforceable in any jurisdiction will, as to such jurisdiction, be ineffective to the extent of such prohibition or unenforceability without invalidating the remaining portions hereof or affecting the validity or enforceability of such provision in any other jurisdiction.

Venue and Choice of Law

This Limited Warranty is applicable in all countries. This Limited Warranty will be governed by the laws of the State of Arizona (regardless of any conflict of laws rules), and any disputes arising from this Limited Warranty will be resolved in Phoenix, Arizona.

Entire Agreement

This Limited Warranty is understood to be the complete and exclusive agreement between GAME and the purchaser of the Product, superseding all prior agreements, oral or written, and all other communications between such parties relating to the Product. No employee or representative of GAME or any other party is authorized to make any warranty in addition to the limited warranty set forth above.

To obtain warranty service, please call, write, or email us directly at the address shown below. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Look for other GAME products at your favorite store or visit our website, www.game-group.com.



Great American Merchandise & Events™
 16444 N. 91st Street
 Scottsdale, AZ 85260-1567 USA

tel: 888.382.5988, 602.957.3825
 fax: 602.957.7665
 email: products@game-group.com
www.game-group.com

DIGITAL WIRELESS THERMOMETER

OWNER'S MANUAL


MODEL 4302



RECEIVER


Front View

1. Transmitter battery strength
2. Temperature
3. Temperature scale
4. Receiver battery strength
5. Signal indicator




Top Buttons Functions

1. Transmitter pairing button
2. Screen light
3. C°/F° button



Receiver Back View

1. Battery compartment
2. Wall mounts




Note

- Always read the owner's manual carefully before operating the unit.
- Avoid placing the receiver near interference sources/metal frames such as computer or TV sets.
- To help conserve batteries and ensure the longest and most accurate product function, the transmitter Unit transmits every 2.5 minutes if the temperature change is 0.5°C/1.1°F or more from the last reading. If the temperature change is less than 0.5°C/1.1°F, the transmitter unit will still transmit every 60 minutes in order to maintain connection. If the Receiver fails to receive a signal within 3 hours, the transmitter Icon will flash, indicating a problem with signal reception.
- Rechargeable batteries rated at less than 1.5 VDC (such as 1.2 VDC rechargeable cells) may adversely affect product range, accuracy, and performance.

WIRELESS TRANSMITTER


Transmitter Front View

1. C°/F° button
2. Battery strength indicator
3. Temperature
4. LCD temperature display
5. Transmitter icon
6. Transmitter pairing button
7. Battery cover
8. Data transmitter LED indicator



Exploded View

1. Battery Cover
2. Transmitter Body
3. Transmitter Cover
4. Tether loops (2)



SPECIFICATIONS

Range of temperature measurement:

Receiver	-0 °C to 50 °C (32°F to 122°F)
Remote transmitter	-50 °C to 70 °C (-58°F to 158°F)
Transmission	100M (300 ft.) open area, RF 433 MHz
Resolution	0.1 degree
Battery life	3 months (alkaline batteries recommended)

RECEIVER BATTERY INSTALLATION

For first time installation, always insert batteries in the receiver display unit and then the remote transmitter. The receiver will seek a transmitter within range.

1. Open the battery cover of the back unit.
2. Install three (3) AAA batteries according to polarity indicated.
3. Replace the batteries compartment cover

SETTING UP THE WIRELESS TRANSMITTER

1. Attach the transmitter cover to the transmitter body
 2. Place the transmitter as close to the receiver as possible.
 3. Remove the battery cap.
 4. Install three (3) AAA batteries according to polarity indicated.
 5. Screw and tighten the battery cap.
 6. The red LED on the transmitter will flash when it transmits a signal. Temperature will be updated and displayed on the transmitter's LCD.
 7. Press the "°C/°F" button on the back of the transmitter to change from Fahrenheit to Celsius.
- NOTE: If the transmitter and receiver fail to automatically pair, bring the two units close together, and press the transmitter button on the receiver for 8 seconds, and then press the transmitter button on the transmitter for 1 second.
8. Place the transmitter into the water to be tested, and check for signal reception at the receiver. For most consistent results, tether the transmitter using the tether loops, and an appropriate length of water, UV, and chemical resistant string.

LOW BATTERY INDICATOR/REPLACING BATTERIES

There are two low battery indication on the receiver and one on the transmitter. A low battery warning icon will appear on the transmitter screen and on the receiver screen.

When the low battery indicator appears, replace the batteries in both the transmitter and receiver. Follow the setup procedure above.

After replacing the batteries, re-pair the receiver with the transmitter by pressing the transmitter pairing button (#6) once.

Note

- Do not mix old and new batteries.
- Do not dispose batteries into fire. Batteries may explode or leak.
- Do not mix alkaline standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Replace batteries ensuring the correct battery type, and as a simultaneous act.
- Remove batteries if product is to be left unused for a long time.
- Clean the battery contacts and also those of the devices prior to battery installation.
- The supply terminal is not to be short circuited (+) (-).
- Non-rechargeable batteries are not to be recharged.
- Batteries are to be inserted with the correct polarity.
- Remove exhausted batteries promptly and dispose of properly.

DÉCLARATION DE GARANTIE LIMITÉE

Le fabricant garantit sécurité et la fiabilité que dans les conditions suivantes:

- Le produit est installé et utilisé selon les instructions de montage et de fonctionnement.
- Seules les pièces de rechange d'origine sont utilisés

Conditions générales

Cette garantie limitée s'applique au produit ci-joint (le "Produit") distribués par Great American Duck Races, Inc., une société Arizona (faisant affaires sous le Great American Marketing and Events) ("GAME").

- GAME garantit que le produit sera exempt de défauts de matériaux et de fabrication dans des conditions normales d'utilisation pour une période de quatre vingt dix (90) jours à compter de la date d'achat. (La facture ou le reçu de livraison, indiquant la date de votre achat du produit, constitue la preuve de la date d'achat.) Au cours de la période de garantie, GAME s'engage à réparer ou remplacer les pièces défectueuses sans frais.
- Toutes les pièces défectueuses sont remplacées par GAME sera remplacé, à la discrétion de GAME, avec des pièces neuves ou pièces usagées qui satisfont ou dépassent les spécifications de performance pour les nouvelles pièces. Toutes les pièces retirées du Produit sous cette garantie deviendront la propriété du GAME. Réparation ou le remplacement de toutes les pièces ne seront pas servir à prolonger la quatre-vingt dix (90) jours la période de garantie.
- Cette garantie limitée ne s'applique pas aux pièces consommables. Cette garantie limitée ne s'étend pas à tout produit (a) dont le numéro de série a été enlevé ou (b) qui a été endommagé ou rendu défectueux (i) à la suite de l'accident, abus ou d'autres causes externes; (ii) Par une opération en dehors des paramètres d'utilisation indiquées dans le manuel fourni avec le produit, (iii) par l'utilisation de pièces non fabriquées ou vendues par GAME; ou (iv) une modification ou réparation par quiconque autre que le gibier ou un distributeur agréé GAME.
- Si un défaut est constaté dans la période de garantie, s'il vous plaît contacter GAME.

SAUF POUR LA GARANTIE LIMITÉE CI-DESSUS, GAME DECLINE EXPRESSEMENT TOUTE AUTRE GARANTIE, EXPLICITE OU IMPLICITE, ORALE ou d'office (Y COMPRIS, SANS LIMITATION, LES GARANTIES DE VALEUR MARCHANDE ET D'ADAPTATION À UN USAGE PARTICULIER). TOUTE GARANTIE IMPLICITE POUVANT ÊTRE IMPOSÉES PAR LA LOI EST LIMITEE AUX TERMES DE LA GARANTIE limitée ci-dessus.

Limitation de responsabilité

SAUF POUR LA GARANTIE LIMITÉE CI-DESSUS, EN AUCUN CAS DE GAME RESPONSABLE DE QUELQUE NATURE QUE CE SOIT (SI contractuelle, civile, OU TOUTE AUTRE THÉORIE DE LA RESPONSABILITÉ JURIDIQUE) A TOUTE PERSONNE EN CE QUI CONCERNE LE PRODUIT (Y COMPRIS, SANS LIMITATION, (A) toute utilisation ou mauvaise utilisation du produit, (B) toute panne ou défaillance DU PRODUIT, (C) des dommages corporels, décès, perte d'OU DOMMAGES AUX BIENS OU DE TOUT AUTRE DOMMAGE liée à ou découlant du produit ou SON UTILISATION (Y COMPRIS, SANS S'Y LIMITER, LES DOMMAGES SPÉCIAUX, INDIRECTS, consécutifs ou punitifs, PERTE DE BÉNÉFICES, PERTE D'UTILISATION), MÊME SI UN REPRÉSENTANT AUTORISÉ GAME ou ont été avisés DE LA POSSIBILITÉ DE TELS DOMMAGES.

Divisibilité

Toute disposition de la présente garantie limitée est interdite ou inapplicable dans un territoire sera, à cette compétence, inefficace dans la mesure d'interdiction ou inapplicabilité sans invalider la portion restante ou à affecter la validité ou la force exécutoire d'une telle disposition dans toute autre juridiction.

Lieu et choix de la loi

Cette garantie limitée est applicable dans tous les pays. Cette garantie limitée sera régie par les lois de l'État de l'Arizona (indépendamment de toute règle de conflit de lois), et tout litige découlant de cette garantie limitée sera résolu à Phoenix, en Arizona.

Intégralité de l'accord

Cette garantie limitée est entendu à l'accord complet et exclusif entre le GAME et l'acheteur du produit, qui annule et remplace toutes les ententes antérieures, verbales ou écrites, et toutes les autres communications entre les parties, touchant au produit. Aucun employé ou représentant d'un GAME ou toute autre partie est autorisée à créer une garantie en plus de la garantie limitée énoncée ci-dessus.

Pour une réparation sous garantie, veuillez nous joindre par téléphone, courrier ou courriel à l'adresse indiquée ci-dessous.

Notre garantie couvre certains droits. Il se peut que d'autres droits existent selon la province où vous habitez.

FCC DÉCLARATION

1. Cet appareil est conforme à la Partie 15 des règlements de la FCC.

Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Ce dispositif ne doit pas causer d'interférences nuisibles et
- (2) Cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent perturber le fonctionnement.

2. Les changements ou modifications non expressément approuvés par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur de faire fonctionner l'équipement.

Rechercher d'autres GAME produits à votre magasin préféré,
ou visitez notre site Web, www.game-group.com.



Great American Merchandise & Events™
16444 N. 91st Street
Scottsdale, AZ 85260-1567 USA

tel: 888.382.5988, 602.957.3825
fax: 602.957.7665
email: products@game-group.com
www.game-group.com

THERMOMÈTRE NUMÉRIQUE SANS FIL

GUIDE D'UTILISATION


MODÈLE 4302



RÉCEPTEUR


Vue avant

1. État des piles de l'émetteur
2. Température
3. Échelle de température
4. État des piles du récepteur
5. Indicateur de signal




Fonctions des boutons supérieurs

1. Bouton de pairage de l'émetteur
2. Éclairage de l'écran
3. Bouton C°/F°



Vue arrière du récepteur

1. Compartiment des piles
2. Installation au mur




Remarque

- Toujours lire le guide d'utilisation attentivement avant de faire fonctionner l'appareil.
- Éviter de placer le récepteur près de sources d'interférence/cadres métalliques, tels qu'un ordinateur ou un téléviseur.
- Pour aider à préserver la durée des piles et à assurer le produit le plus durable et le plus précis, l'émetteur transmet toutes les 2,5 minutes si le changement de température est de 0,5 °C/1,1 °F ou plus depuis la dernière lecture. Si le changement de température est inférieur à 0,5 °C/1,1 °F, l'émetteur transmettra toutes les 60 minutes pour maintenir la connexion. Si le récepteur ne reçoit aucun signal pendant 3 heures, l'icône de l'émetteur clignotera pour indiquer qu'il y a un problème avec la réception de signal.
- Les piles rechargeables de moins de 1,5 V c.c. (comme les piles rechargeables de 1,2 V c.c.) peuvent avoir un effet nuisible sur la portée, la précision et la performance du produit.

ÉMETTEUR SANS FIL


Vue avant de l'émetteur

1. Bouton C°/F°
2. Indicateur d'état des piles
3. Température
4. Affichage ACL de la température
5. Icône de l'émetteur
6. Bouton de pairage de l'émetteur
7. Couvercle du compartiment des piles
8. Indicateur à DEL de l'émetteur de données



Vue éclatée

1. Battery Cover
1. Couvercle du compartiment des piles
2. Boîtier de l'émetteur
3. Couvercle de l'émetteur
4. Boucles de sangle (2)



SPÉCIFICATIONS

Mesure de la gamme de températures :

Récepteur	-0 °C à 50 °C (32 °F à 122 °F)
Émetteur à distance	-50 °C à 70 °C (-58 °F à 158 °F)
Transmission	Aire ouverte de 100 M (300 pi), RF 433 MHz
Résolution	0,1 degré
Durée des piles	3 mois (piles alcalines recommandées)

INSTALLATION DES PILES DANS LE RÉCEPTEUR

La première fois, insérer les piles d'abord dans le récepteur à écran d'affichage, puis dans l'émetteur à distance. Le récepteur cherchera un émetteur à portée.

1. Ouvrir le couvercle du compartiment des piles à l'arrière du récepteur.
2. Insérer trois (3) piles AAA en respectant la polarité indiquée.
3. Replacer le couvercle du compartiment des piles.

INSTALLATION DE L'ÉMETTEUR SANS FIL

1. Visser le couvercle de l'émetteur dans le boîtier de l'émetteur.
2. Placer l'émetteur le plus près possible du récepteur.
3. Retirer le capuchon du compartiment des piles.
4. Insérer trois (3) piles AAA en respectant la polarité indiquée.
5. Visser et serrer le capuchon du compartiment des piles.
6. Le voyant à DEL rouge sur l'émetteur clignotera lorsque l'émetteur transmettra un signal. La température de l'émetteur sera mise à jour et s'affichera sur l'écran ACL de l'émetteur.
7. Appuyer sur le bouton °C/°F à l'arrière de l'émetteur pour passer des degrés Fahrenheit aux degrés Celsius.

Remarque : Si l'émetteur et le récepteur ne s'apparient pas automatiquement, rapprocher les deux appareils et appuyer sur le bouton de l'émetteur sur le récepteur pendant huit (8) secondes, puis appuyer sur le bouton de l'émetteur sur l'émetteur pendant une (1) seconde.

8. Placer l'émetteur dans l'eau pour faire un essai, puis vérifier la réception de signal sur le récepteur. Pour obtenir les résultats les plus constants, attacher l'émetteur à l'aide des boucles de sangle et d'une ficelle d'une longueur appropriée qui résiste à l'eau, aux rayons ultraviolets et aux produits chimiques.

INDICATEUR DE PILE FAIBLE

Il y a deux indicateurs de pile faible sur le récepteur et il y en a un sur l'émetteur. L'icône d'avertissement de pile faible s'affichera sur l'écran de l'émetteur et sur l'écran du récepteur.

Lorsque l'indicateur de pile faible s'affiche, remplacer les piles dans l'émetteur et le récepteur. Suivre les directives d'installation ci-dessus.

Après avoir remplacé les piles, apparier à nouveau le récepteur avec l'émetteur en appuyant une fois sur le bouton de pairage de l'émetteur (no 6).

Remarque

- Do not mix old and new batteries.
- Do not dispose batteries into fire. Batteries may explode or leak.
- Do not mix alkaline standard (carbon-zinc), or rechargeable (nickel-cadium) batteries.
- Replace batteries ensuring the correct battery type, and as a simultaneous act.
- Remove batteries if product is to be left unused for a long time.
- Clean the battery contacts and also those of the devices prior to battery installation.
- The supply terminal is not to be short circuited (+) (-).
- Non-rechargeable batteries are not to be recharged.
- Batteries are to be inserted with the correct polarity.
- Remove exhausted batteries promptly and dispose of properly.