









ITEM NAME/NOM D'ITEM:HORTEN ACCENT CHAIR


ITEM #/NO. ITEM:110025/110026

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(4)
 x1	 x1	 x1	A.  M6x35mm x 8 B.  x 4 C.  5mm x 1

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I




II




III




IV




V



VI



VII



For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler:

USA, Canada and Mexico: (866)-798-6663

AI-V1- 231124