

Assembly Guide




If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-950-4782.

Our customer service experts are trained to provide step-by-step instruction and can easily replace any missing or damaged parts.

Representatives are available Monday-Friday from 8:30 a.m. to 7:30 p.m. (ET)

30W Storage Cabinet



Lot Code #

Instruction Sheet Number A173950G

Keep manual for future reference.

For best results, keep these tips in mind:

- ① We know you want to finish this assembly as quickly as possible, but trust us: you'll have a better experience if you take it one step at a time.
- ② Give yourself some room to work near where you want the fully assembled product.
- ③ If your floor isn't carpeted, assemble this product on the empty carton to avoid scratching.
- ④ Do you have a friend who owes you a favor? Some steps may go a little easier with a second set of hands.

DOs

- ✓ Use a #2 Phillips head screwdriver (or other handheld tools as indicated)
- ✓ Wear safety glasses at all times during assembly
- ✓ Carefully follow the instructions in this guide and complete all steps in order
- ✓ Give us a call if you're having trouble with a particularly tricky step

DON'Ts

- ✗ We know power tools are quick and easy, but you shouldn't use them when assembling this product (unless otherwise specified)
- ✗ Never move your furniture with items inside or resting on the surface
- ✗ Do not attempt to use this product before all steps have been completed



Watch assembly videos right on your phone or computer!



Some steps include QR codes that link to helpful videos. Watch out for the icon below! Simply open up your smartphone camera to scan the code.

(Users of older smartphones may need to install a QR Reader.)

SCAN HERE



FOR VIDEOS

Or visit <https://bushfurniture.com/help-faq/#assembling>

IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS

Improper use can cause safety hazards, or damage to your furniture and household items.

Warning	Do	Don't	Why it's important
Serious injury may occur.	- Assemble following all instructions using all indicated parts and hardware provided. - Install every indicated nail and/or screw. - Verify that furniture is stable on it's own. - Place heaviest items in the lower drawers or shelves. - Remove items that might tempt kids to climb, such as toys and remote controls from the top and upper shelves of furniture.	- Do not move unit when loaded. - Do not load with a television or other heavy equipment. - Do not exceed the maximum load limits stated in the instructions. - Do not allow children to stand, climb, or hang on furniture.	Improper assembly, use or loading can lead to product instability, tipover, or collapse.

Advertencia	Hacer	No	Por qué es importante
Pueden producirse lesiones graves.	- Realice el montaje siguiendo todas las instrucciones y utilizando todas las piezas indicadas y los herrajes suministrados. - Instale todos los clavos y/o tornillos indicados. - Compruebe que el mueble sea estable por sí mismo. - Coloque los objetos más pesados en los cajones o estantes inferiores. - Retire los objetos que puedan tentar a los niños a trepar, como juguetes y mandos a distancia, de los estantes superiores y superiores del mueble.	- No mueva la unidad cuando esté cargada. - No cargue el mueble con un televisor u otro equipo pesado. - No supere los límites máximos de carga indicados en las instrucciones. - No permita que los niños trepen o se cuelguen de los muebles.	El montaje, uso o carga inadecuados pueden provocar inestabilidad, vuelco o colapso del producto.



IMPORTANT SAFETY INFORMATION



PLEASE READ WARNINGS


Improper use can cause safety hazards, or damage to your furniture and household items.


Avertissement	À faire	À ne pas faire	Pourquoi c'est important
Peut entraîner des blessures graves.	• Assembler en suivant toutes les instructions et en utilisant toutes les pièces et la quincaillerie incluses. • Installer tous les clous et/ou toutes les vis. • Assurez-vous que le meuble soit stable par lui-même. • Placer les objets les plus lourds sur les tablettes ou dans les tiroirs du bas. • Retirer les objets qui pourraient inciter les enfants à grimper comme les jouets et les télécommandes des tablettes supérieures et du dessus du meuble.	• Ne pas déplacer le meuble lorsqu'il est chargé. • Ne pas charger le meuble avec un téléviseur ou tout autre équipement lourd. • Ne pas dépasser les limites de poids maximales indiquées dans les instructions. • Ne pas laisser les enfants grimper ou s'accrocher aux meubles.	Un assemblage, une utilisation ou un chargement incorrects peuvent entraîner l'instabilité, le basculement ou l'effondrement du produit.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.


Fasteners are shown actual size.

H192100  [2]
#8 x 1/2"

 [4]













H38169  [1]
Wood Dowel 8 x 30

H72988  [17]
KD Bolt

H181468US  [17]
KD Cam3000

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

Hardware not to scale.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 1

Prepare Panel



A173950G

H72988



KD Bolt

[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 2

Assemble Panels

A173950G

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468US




[2]



1



2



3



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 3

Prepare Panel

A173950G

H38169



Wood Dowel 8 x 30


[1]

H72988





KD Bolt

[2]



Safety glasses
Gafas de seguridad
Lunettes de protection



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 4

Assemble Panels

A173950G

Scan QR Code to
Watch Video on:





How to Tighten
KD Cams

H181468US



[2]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 5

Prepare Panel

A173950G


H72988



KD Bolt


[4]

H209601



Leveler

[2]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 6

Assemble Panels


A173950G

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams


Team Lift



H181468US





KD Cam3000



Cover Cap

[4]

[2]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 7

Prepare Panel


A173950G

H72988 [4]







KD Bolt

H209601 [2]



Leveler



Safety glasses
Gafas de seguridad
Lunettes de protection

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 8

Assemble Panels

A173950G



Scan QR Code to
Watch Video on:

H181468US




How to Tighten
KD Cams

Team Lift





KD Cam3000



Cover Cap

[4]

[2]




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 9



Prepare Panel

A173950G

H72988  [5]
KD Bolt

H27170  [1]
"L" Bracket

H192100  [1]
#8 x 1/2"



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 10

Assemble Panels

A173950G

Scan QR Code to
Watch Video on:




How to Tighten
KD Cams

H181468US



KD Cam3000



Cover Cap

[5]







[5]

1

2

3

4




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 11

Prepare Panel


A173950G

Z82396




[1]

Cam Lock Assy




[2]

H122276



[1]


Lock Arm



[1]


Handle

H214969



[2]

Hinge




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 12

Prepare Panel


A173950G

H24929




Strike plate

[1]



[2]

H214969



Hinge


[2]

H192100




#8 x 1/2"

[1]



Handle

[1]



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 13

Attach Panels


A173950G

H215406








[2]

Bumper



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.




Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 15

Insert Hardware and Panel

A173950G


H23604



Shelf Pin


[4]

H126396




Shelf Pin Sleeve

[4]




Grommet

[1]



4X



Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

STEP 16

Maximum Loading and Cleaning

A173950G


Scan QR Code to
Watch Video on:




How to Clean
the Surface

Gently clean surfaces with
a damp sponge eraser.

Maximum Weight: 125 Lbs.
Peso Máximo: 125 Libras
Poids Maximum: 56.7 kilogramme



Maximum Weight: 50 Lbs.
Peso Máximo: 50 Libras
Poids Maximum: 22.7 kilogramme







Congratulations! You are all done. If you
have any questions or concerns, please call.

Have an assembly question or need a replacement part? Just call
1-800-950-4782, we are here to help.

WC12996A

A	[1]	W221776
B	[1]	W186319
C	[1]	W186320
D	[1]	W129016
E	[1]	W129017
F	[1]	W129018
G	[1]	W220759
H	[1]	W183318
I	[1]	W220758



WC24496A

A	[1]	W221775
B	[1]	W186321
C	[1]	W186322
D	[1]	W129974
E	[1]	W129975
F	[1]	W129976
G	[1]	W220757
H	[1]	W183319
I	[1]	W220756

