

ITEM# 87385








Westwood Cherry 25" H, 46" W Corner W/Storage



Leick
Home
SINCE 1910

2219 S. 19th St.
Sheboygan, WI 53081
Ph: 920-451-4060
Fax: 920-451-4063
info@leickfurnituresince1910.com

Hardware List






Item	Description	Qty
a	 Bolt 1/4" * 1-1/8"	3PCS
b	 Allen wrench	1PC
c	 Washer 1/4" * 12mm	3PCS
d	 Shelf metal clip	12PCS
e	 Bigger Shelf metal clip	2PCS
f	 Door Pull	3PCS
g	 Machine screw for door pull 5/32" * 3/4"	3PCS

Parts List

Item	Description	Qty
A	Cabinet	1PC
B	Top Panel	1PC
C	Side Back Panel	2PCS
D	Middle Bottom Panel	1PC
E	Left Side Bottom Panel	1PC
F	Right Side Bottom Panel	1PC
G	Middle Adjustable Shelf	1PC
H	Left Side Adjustable Shelf	1PC
I	Right Side Adjustable Shelf	1PC

Assembly Instructions

Two person assembly recommended.

<p>step 1 Unfold Cabinet.</p> 	<p>step 2 Install two bigger shelf clips on the side bottom.</p> 
<p>step 3 Insert the center bottom panel first, then insert the side bottom panel.</p> 	<p>step 4 Insert two side back panels.</p> 
<p>step 5 Bolt on top with 3 bolts.</p> 	<p>step 6 Install shelf clips and insert shelves and door pulls.</p> 