

FLEXSTEEL®




W1029-01

End Table

IMPORTANT


Carefully remove all parts from the carton, and put them individually on a soft cloth to prevent damage to the parts.

We have taken great care in the design of this product and request that you carefully and accurately follow our assembly instructions to ensure proper set-up.




Part List


Assembly Instructions 1/3



A. Table Top
1 piece




B. Leg
2 pieces



C. Bottom Shelf
1 piece

Hardware List




1. Bolt
Ø5/16"-18 UNC * 1-1/2"
12 pieces



2. Spring Washer
Ø5/16" * Ø12 * 1.5mm
12 pieces



3. Flat Washer
Ø5/16" * Ø19 * 1.5mm
12 pieces



4. Hex Key
4mm
1 piece

FLEXSTEEL®

Assembly Instructions 2/3


IMPORTANT NOTES

- Do not tighten up all the screws until each part is properly assembled.
- You should keep Allen Key in a safe place as you may need to tighten up the Bolt in the future.
- Use a soft cloth between these parts and the floor.

STEP 1


Place Table Top (A) upside down on a clean, smooth surface. Attach Leg (B) and Table Top (A) with the Bolts (1), Spring Washers (2) and Flat Washers (3). Use Allen Key (4) to tighten the bolts (1). (See Figure 1)

Note: We recommend at least two adults assemble this item.



STEP 2

Attach Bottom Shelf (C) to the Legs (B) with Bolts (1), Spring Washers (2), and Flat Washers (3), and tighten with Allen Key (4). (See Figure 2).



FLEXSTEEL®


Assembly Instructions 3/3

IMPORTANT NOTES

- Do not tighten up all the screws until each part is properly assembled.
- You should keep Allen Key in a safe place as you may need to tighten up the Bolt in the future.
- Use a soft cloth between these parts and the floor.

STEP 3

Adjust the levelers on the Legs (B) until the furniture is level. (See Figure 3)



CARE INSTRUCTIONS

- To avoid scratches, do not place sharp or jagged objects directly on the table top.
- Do not place hot items directly on the table top.
- Use placemats or trivets under hot items and coasters under beverages to prevent marks and stains.
- Avoid the use of harsh chemicals or abrasive cleaning materials.
- Wipe the table clean with a soft, dry cloth after each use.
- Wipe up spills quickly with a soft, dry cloth.

Flexsteel Industries, Inc.

For Parts or Customer Service call

toll-free:

1-888-415-3979

Monday-Friday

8:00 a.m. -5:00 p.m.

(Central Time)

Email:

customersolutions@flexsteel.com

www.flexsteel.com