


SHIMANO

CHRONARCH SA-RB

CH-51E



Part No.	Description	Part No.	Description	Part No.	Description
BNT0011	Screw	BNT3426	Clutch Pawl	BNT4177	Drive Shaft
BNT0015	Drag Spring Washer	BNT3483	Anti-Reverse Ratchet	BNT4179	Pinion Gear
BNT0031	Ball Bearing	BNT3568	Star Drag Nut	BNT4217	Spool Tension Spring
BNT0032	Bearing Retainer	BNT3748	Screw	BNT4219	Handle Retainer
BNT0060	Spacer	BNT3763	Side Plate Spring	BNT4227	Cast Control Cap
BNT0194	Ball Bearing	BNT3818	Drive Shaft Retainer	BNT4228	Drag Washer
BNT0609	Screw	BNT3918	Washer	BNT4231	Pawl Cap
BNT0623	Screw	BNT3927	Ball Bearing	BNT4240	Handle Knob
BNT0664	Spacer B	BNT3934	Brake Case Spacer	BNT4242	Star Drag
BNT0686	E Lock	BNT3935	Brake Spring Retainer	BNT4249	Turnkey Dial
BNT1356	Screw	BNT3936	Click Spring	BNT4256	Handle Shank Assembly
BNT1419	Yoke Spring	BNT3937	Click Pin	BNT4259	Level Wind Guard
BNT1636	Screw	BNT4009	Idle Gear	BNT4261	Line Guide
BNT1671	Washer	BNT4035	Star Drag Spring	BNT4264	Spool Assembly
BNT1672	E Lock	BNT4036	Line Guide Pawl	BNT4266	Handle Assembly
BNT1696	Cast Control Spacer	BNT4052	Clutch Cam Retainer	BNT4267	Left Side Plate
BNT1715	Brake Collar (red)	BNT4075	Clutch Plate	BNT4268	Level Wind Protector
BNT2122	Click Pin	BNT4077	Clutch Bar Guide	BNT4269	Quick-Fire II Clutch Bar
BNT2127	Star Drag Spacer	BNT4082	Brake Case	BNT4270	One-Piece Frame
BNT2144	Washer	BNT4116	Screw	BNT4271	Right Side Plate
BNT2200	Handle Nut	BNT4120	Ball Bearing	BNT4272	Screw
BNT2224	Spool Tension Spacer	BNT4150	Handle Knob Seal	BNT4308	Anti-Reverse Pawl
BNT2431	Drag Washer	BNT4151	Washer	BNT4416	Yoke
BNT2622	Clutch Cam	BNT4157	Roller Clutch Inner Tube	BNT4503	Clutch Pawl Spring
BNT2717	E Lock	BNT4160	Idle Gear	BNT4931	Click Spring
BNT2964	Screw	BNT4161	Washer		
BNT3041	Clutch Plate Shaft Support	BNT4162	Worm Shaft		
BNT3208	Star Drag Click Plate	BNT4166	Level Wind Guide	BNT1713	Brake Collar (green) (accessory)
BNT3213	Key Washer	BNT4176	Drive Gear	BNT3237	Wrench (accessory)