


homestyles[®]

20 05033 0944

Kitchen Island




IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.

Part List



A2.
Top
1 pc.



A1.
Top
1 pc.

For assembly see instructions in carton 20 05033 0945.

Tools required for unpacking: Phillips screwdriver, hammer

Home Styles Customer Service: www.homestyles-furniture.com,
servicedesk@homestyles-furniture.com, 888-680-7460, 877-831-0319