MODPLAY®

Playsets

UPPER ENCLOSURE X L
Assembly Instructions





PG-MAN-ENC-PH-XL-00


817 Maxwell Avenue • Evansville, IN 47711 • 1-800-GO-SWING • www.escaladesports.com • ©2018 Escalade Sports

STANDARD PARTS LIST

NOTE: Parts will have the part number (Starts with PG-) stamped on the part itself.









ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	PG-2X4-025-WB	Window Bottom	4
2	PG-544-025-WT	Window Top	4
3	PG-ENC-027-LO	Left Outside Enclosure Board	2
4	PG-544-031-ENC	30 5/8" Enclosure Board	4
5	PG-546-018-ENC	17 1/2" Enclosure Board	6
6	PG-546-024-ENC	Enclosure Board Short	6
7	PG-544-047-ENC-B	47" Enclosure Board	4
8	PG-ENC-051-LI	Left Inside Enclosure Board	2
9	PG-544-061-WT	60 5/8" Window Top	1
10	PG-544-061-ENC	Window Bottom Filler	1
11	PG-544-014-ENC	Enclosure Board Short	6
12	PG-546-014-ENC	Enclosure Board Short	2
13	PG-2X4-054-RFT	53 1/2" Enclosure Rafter	1
14	PG-546-012-ENC	12 1/2" Enclosure Board	2
15	PG-HW-S011	#10X3" PH FLAT HD WDSCR	38
16	PG-HW-S018	#10 X 1-3/4" Flat Head Screw	176
17	PG-ENC-051-RI	Right Inside Enclosure Board	2
18	PG-ENC-027-RO	Right Outside Enclosure Board	2
19	PG-HW-W002	1/4" FLAT WASHER	4
20	PG-HW-L009	1/4 x 3" Hex Lag Screw	4


HARDWARE NEEDED




1/4 x 3" Hex Lag Screw **PG-HW-L009** QTY.4



1/4" FLAT WASHER PG-HW-W002 QTY.4



#10 X **3**" PHILLIPS FLAT HEAD WOODSCREW **PG-HW-S011**QTY. 38



#10 X **1-3/4**" Flat Head Screw **PG-HW-S018**QTY. 176



NOTE

COMPLETE ASSEMBLY OF YOUR PLAYSET & WOOD ROOF BEFORE ADDING THIS UPPER ENCLOSURE.





Parts will have the part number (Starts with PG-) stamped on the part itself.


HARDWARE NEEDED (ACTUAL SIZE)

#10 X **3**" PHILLIPS FLAT HEAD WOODSCREW **PG-HW-S011**QTY. 18

- 1. Attach PG-ENC-051-RI & PG-ENC-51-LI to Vertical roof support with six screws each as shown in Inside View. Line up both parts to Vertical Roof Support and Safety Rail as shown in Detail A.
- **2.** Attach PG-ENC-027-**RO** & PG-ENC-027-**LO** to Corner posts. See **Inside View**.










3. Attach each board to the Rafter at the top with two **PG-HW-S018** screws as shown in the **Inside view** and **Detail B**.










- 4. Attach two PG-544-025-WT with one screw on each end as shown in the Inside View & Outside View. Line up the boards flush as shown in Detail C.
- **5.** Attach two **PG-2x4-025-WB boards**-with two screws on each end as shown in the **Inside View**. Line up the boards flush as shown in **Detail D**.









- 6. Attach boards as shown in the Inside View & Outside View. Space boards evenly and fasten with PG-HW-S018 screws.
- **7.** Repeat Steps **1-6** on other end to enclose the back part of the playset.









8. Center boards PG-544-061-ENC and RW-544-061-WT in between Corner Posts and attach with Lag screws & Washers as shown in Detail E & Outside View.










9. Space boards evenly and attach boards PG-544-014-ENC & PG-546-014-ENC with four PG-HW-S018 screws each. See Inside View & Outside View.










10. Install RW-2x4-054-RFT board with two PG-HW-S011 screws as shown in Detail F and the Inside View. Make sure board is level in between rafters.








- 11. Measure 18 3/8" from the Corner post and attach a PG-546-024-ENC board with four screws. Then Space boards PG-546-018-ENC & PG-546-012-ENC evenly and attach to fill in the gaps. See Inside View & Outside View.
- **12.** Repeat for other side.





Consumer Information Sheet for Playground Surfacing Materials¹

The U.S. Consumer Product Safety Commission (CPSC) estimates that about 100,000 playground equipment-related injuries resulting from falls to the ground surface are treated annually in the U.S. hospital emergency rooms. Injuries involving this hazard pattern tend to be among the most serious of all playground injuries, and have the potential to be fatal, particularly when the injury is to the head.

The surface under and around playground equipment can be a major factor in determining the injury-causing potential of a fall. It is self evident that a fall onto a shock absorbing surface is less likely to cause a serious injury than a fall onto a hard surface. Playground equipment should never be placed on hard surfaces such as concrete or asphalt and while grass may appear to be acceptable it may quickly turn to hard packed earth in areas of high traffic. Shredded bark mulch, wood chips, fine sand or fine gravel are considered to be acceptable shock absorbing surfaces when installed and maintained at a sufficient depth under and around playground equipment.

The following table lists the maximum height from which a child would not be expected to sustain a life-threatening head injury in a fall onto four different loose-fill surfacing materials if they are installed and

maintained at depths of 6", 9", and 12". However, it should be recognized that all injuries due to falls cannot be prevented no matter what surfacing material is used.

It is recommended that a shock absorbing material should extend a minimum of 6' in all directions from the perimeter of stationary equipment such as climbers and slides. However, because children may deliberately jump from a moving swing, the shock absorbing material should extend in the front and rear of a swing a minimum distance of 2 times the height of the pivot point measured from a point directly beneath the pivot point supporting structure.

This information is intended to assist in comparing the relative shock-absorbing properties of various materials. No particular material is recommended over another. However, each material is only effective when properly maintained. Materials should be checked periodically and replenished to maintain correct depth as determined necessary for your equipment. The choice of a material depends on the type and height of the playground equipment, the availability of the material in your area, and its cost.

FALL HEIGHT IN FEET FROM WHICH A LIFE THREATENING HEAD INJURY WOULD NOT BE EXPECTED

TYPE OF MATERIAL	6" рертн	9" рертн	12" рертн
Double Shredded Bark Mulch	6'	10'	11'
Wood Chips	6'	7'	12'
Fine Sand	5'	5'	9'
Fine Gravel	6'	7'	10'

¹This information has been extracted from the CPSC publications "Playground Surfacing—Technical Information Guide" and "Handbook for Public Playground Safety." Copies of these reports can be obtained by sending a postcard to the Office of Public Affairs, U.S. Consumer Product Safety Commission, Washington, D.C. 20207. Or call the toll-free hotline: 1-800-638-2772.



2016 WARRANTY

5 Year Warranty

Subject to proper installation and normal residential use, Woodplay warrants, subject to the limitations stated below, to the original retail purchaser, all chain, seats, swing hangers, hardware, metal braces, ropes and accessories to be free from defects in material and workmanship for a period of **five years** from date of purchase. Cracks in non -functional plastic components are not considered defects in materials and workmanship if they do not affect the functionality of the playset. Merchandise covered under this limited **five-year** warranty will, at our option, be repaired or replaced, excluding any freight or labor fees.

15 Year warranty

In addition, for **Fifteen years** after the original purchase date of our **Cedar** playsets, Woodplay warrants, to the original retail purchaser, all wooden components against structural failure due to corrosion, wood rot, or insect infestation. Seasonal checks, surface cracks, knotholes and knots, natural characteristics of all wooden play equipment, not resulting in structural failure, are not covered under this warranty. And will not affect the integrity of your playset.

Limited Lifetime Warranty

In addition, for the **lifetime** of our **Redwood** playsets, Woodplay warrants, to the original retail purchaser, all wooden components against structural failure due to corrosion, wood rot, or insect infestation. Seasonal checks, surface cracks, knotholes and knots, natural characteristics of all wooden play equipment, not resulting in structural failure, are not covered under this warranty. And will not affect the integrity of your playset. Woodplay warrants to the original retail customer that we will replace any swing hangers, swing chains, metal braces, metal rungs or hardware that fail due to rust or breakage (excludes surface rust). This limited lifetime warranty also applies to our exclusive Super Slide, Hurricane Slide and Alpine Slide.

Timber is a natural material which can absorb and release moisture. Although this product is designed to minimize this effect, in certain circumstances some movement or distortion is unavoidable. During dry hot weather timber may shrink and check - this is a normal process of weathering. After the first year of service it is advisable to clean and apply a non-toxic stain or sealant to the wood, safe for children's use.

Components covered under this **5 year**, **15 year** and limited **lifetime warranty** will be replaced free of charge <u>excluding</u> freight and labor fees.

Non-residential use of the playset is prohibited and voids the warranty as the playsets are designed for residential use only.

Escalade Sports reserves the right to examine photographs and/or physical evidence of merchandise claimed to be defective, and to recover said merchandise, prior to disposition of warranty claims. Merchandise returned to our factory for examination or recovery must be shipped freight prepaid, unless a Return Authorization Number is issued.

This warranty program does not cover normal wear and tear, color fading, or damages resulting from misuse, abuse, vandalism, alteration, acts of God, or assembly and maintenance contrary to our instructions. Escalade Sports assumes no responsibility for incidental or consequential damages which may arise from the purchase or use of our equipment. Please supervise your children's play activity and maintain your play equipment periodically.

This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Woodplay does not assume or authorize any person to assume for us, any other liability in connection with the sale of our products.

Special Note: Woodplay reserves the right to make changes in materials, design, and pricing without notice. See your instruction manual for maintenance requirements. Your child's safety is your responsibility; therefore, you should inspect this equipment regularly for wear and safety.

For warranty service, contact:

Woodplay Playsets
Escalade Sports
P.O. Box 889
Evansville, IN 47706
1-800-GO-SWING

Or E-Mail us at: playgroundcs@escaladesports.com