

BOX 1 - HEADBOARD				BOX 3 - SIDERAILS			
PART NO.	IMAGE	DESCRIPTION	QUANTITY	PART NO.	IMAGE	DESCRIPTION	QUANTITY
A		HEADBOARD	1	G		SIDERAIL	2
В		LEFT HEADBOARD LEG	1	BOX 4 - S PART NO.	LAT ROLL IMAGE	DESCRIPTION	QUANTITY
С		RIGHT HEADBOARD LEG	1	н		SLAT ROLL	1
HARDWA	RE KIT PA	CKED IN BOX 1					
1		ALLEN BOLT (6X35mm)	8			R BOX MAY CONTAIN	
2	0	SPRING WASHER (M6)	8				
3	0	FLAT WASHER (M6)	8		<u> </u>	0:30	
4		ALLEN KEY	1			NOT PRO	


1

BOX 2 - STORAGE FOOTBOARD


PART NO.	IMAGE	DESCRIPTION	QUANTITY				
D		STORAGE FOOTBOARD	1				
E	CENTER SLAT		1				
F		LEG SUPPORT	3				
HARDWARE KIT PACKED IN BOX 2							
5	3	WOOD SCREW (8X30mm)	9				
6		ALLEN BOLT (6X40mm)	10				

ALLEN KEY

ASSEMBLE ON A SOFT SURFACE




STEP 1: USE HARDWARE KIT PACKED IN BOX 1 FOR STEP 1.



7


UPDATED: JULY 26TH, 2023






STEP 2:


USE HARDWARE KIT PACKED IN BOX 2 FOR STEP 2 AND ALL REMAINING STEPS.




STEP 3:





STEP 4:





















STEP 10:





STEP 12:



ASSEMBLY COMPLETE

INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each leg support (**F**).

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the center slat.

UPDATED: JULY 26TH, 2023



- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

