



59"×35.4" OUTDOOR STEEL RECTANGULAR DINING TABLE

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com

FOLLOW, SHARE, & LEARN













PRODUCT REGISTRATION

https://westintrends.com/apps/product-registration



(!) CARE & MAINTENANCE

Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Inspect and tighten all bolts on a regular basis to ensure proper performance and safety.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- We recommend the use of furniture covers to protect when not in use, and store in a dry and protective area during off season.

TOOLS REQUIRED










HARDWARE






PARTS





PRODUCT ASSEMBLY - OVERALL VIEW

Look at following overall view of this table and learn the exact position of each part to be assembled.




PRODUCT ASSEMBLY



Pick out Part B Table Leg and Part A Table Top from package.

Place Part A Table Top upside down on flat surface. Attach 4 pcs of Part B Table Leg to Part A Table Top, each leg with 4 sets of Hardware #1 Bolt and #2 Washer.




2

Check and tighten all the bolts again to ensure the table is steady enough.

Adjust the feet leveler to ensure four feet are evenly to the ground.

Enjoy the table now.



REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy



HAVING TROUBLE

• Not sure how to assemble or missing pieces?
Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap, rinse thoroughly and dry in the sun. Avoid harsh cleansers or polish and do not use bleach or acid on the metal product.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.