



Purchase Date: \_\_\_ / \_\_\_ / \_\_\_ Order/Customer Reference #: \_\_\_\_\_

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: [customerservice@sunnydazedecor.com](mailto:customerservice@sunnydazedecor.com), or via our contact us page at <https://tiny.cc/SunnydazeContact>

# DECORATIVE PLANTER

Please read this manual carefully before use and save it for future reference.

## USE & CARE

**FILLING:** Lightweight potting soil is recommended for filling the planter.

**WATERING:** Take care not to over-water plants.

**EXPOSURE:** Over time, sunlight and weather elements may degrade and change the color of this product.

**MOVING:** Always lift the planter from the bottom when moving it, lifting by the decorative elements of the planter may cause it to break. Slowly and gently set the planter down to prevent breakage.

**CLEANING:** Gently brush loose debris using a soft-bristle brush, like a paintbrush. Rinse under a faucet using lukewarm water and allow to air dry.

**WINTER CARE & STORAGE:** Store in a dry, indoor location. To prevent cracking, empty and store indoors during freezing temperatures.

**Any modification to the product or failure to follow recommended care will void the product warranty.**

**⚠ WARNING:** Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

