


INSTRUCTION MANUAL



Classic Porch Rocking Chair

v1.0

! NOTICE

Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Use a rubber mallet to carefully secure the mortise and tenon joint together.

TOOLS REQUIRED



ALLEN WRENCH
(PROVIDED)



SCREWDRIVER
BLADES
(PROVIDED)



CHAIR
330 LBS
CAPACITY



1 PERSON
ASSEMBLY



UP TO 30 MIN.
ASSEMBLY

HARDWARE

1

SCREW
M6.3 x 80mm



10 PCS

2

SCREW
M6.3 x 60mm



12 PCS

3

SCREW
M4.2 x 60mm



4 PCS

4

SCREW
M4.2 x 35mm



4 PCS

PARTS

A


BACKUP
PLATE



1 PC

B

CHAIR
BACKREST



1 PC

C

RIGHT
FRONT LEG



1 PC

D


LEFT
FRONT LEG



1 PC


E

RIGHT
BACK LEG




1 PC

PARTS



PRODUCT ASSEMBLY – OVERALL VIEW

Look at following overall view of this chair and learn the exact position of each part to be assembled.



PRODUCT ASSEMBLY

1


Attach **Part G Left Chair Arm** and **Part I Side Rail** to **Part F Left Back Leg** with 2 pcs of **Hardware #1 Screw**.

Attach **Part G Left Chair Arm** to **Part D Left Front Leg** with 2 pcs of **Hardware #3 Screw**.

(Both Allen wrenches and screwdriver blades can be used for screwdriving.)

Attach **Part I Side Rail** to **Part D Left Front Leg** with 1 pc of **Hardware #1 Screw**.

Use a rubber mallet to carefully secure the mortise and tenon joint together.



2


Attach **Part H Right Chair Arm** and **Part I Side Rail** to **Part E Right Back Leg** with 2 pcs of **Hardware #1 Screw**.

Attach **Part H Right Chair Arm** to **Part C Right Front Leg** with 2 pcs of **Hardware #3 Screw**.

(Both Allen wrenches and screwdriver blades can be used for screwdriving.)

Attach **Part I Side Rail** to **Part C Right Front Leg** with 1 pc of **Hardware #1 Screw**.

Use a rubber mallet to carefully secure the mortise and tenon joint together.




PRODUCT ASSEMBLY

3


Attach **Part L Rocking Feet** to **Part E Right Back Leg** and **Part C Right Front Leg** with 2 pcs of **Hardware #1 Screw**.

Attach **Part L Rocking Feet** to **Part F Left Back Leg** and **Part D Left Front Leg** with 2 pcs of **Hardware #1 Screw**.



4

Attach **Part N Chair Seat Back Board** to **Part M Chair Seat** with 4 pcs of **Hardware #4 Screw**.



PRODUCT ASSEMBLY


5

Attach **Part A Backup Plate** and **Part B Chair Backrest** to **Part E Right Back Leg** with 2 pcs of **Hardware #2 Screw**.

Attach **Part M Chair Seat** to **Part E Right Back Leg** and **Part C Right Front Leg** with 2 pcs of **Hardware #2 Screw**.

Attach **Part K Front Rail** to **Part C Right Front Leg** and attach **Part J Back Rail** to **Part E Right Back Leg** with 2 pcs of **Hardware #2 Screw**. Use a rubber mallet to carefully secure the mortise and tenon joint together.

(Remark: **Part B Chair Backrest** have 2 different sides. The front side is the side without the Prop 65 warning label.)



PRODUCT ASSEMBLY


6

Attach **Part A Backup Plate** and **Part B Chair Backrest** to **Part F Left Back Leg** with 2 pcs of **Hardware #2 Screw**.

Attach **Part M Chair Seat** to **Part F Left Back Leg** and **Part D Left Front Leg** with 2 pcs of **Hardware #2 Screw**.

Attach **Part K Front Rail** to **Part D Left Front Leg** and attach **Part J Back Rail** to **Part F Left Back Leg** with 2 pcs of **Hardware #2 Screw**. Use a rubber mallet to carefully secure the mortise and tenon joint together.

Check and tighten all the bolts and screws again to finish the assembly.



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.