








ITEM# 87401
 Westwood Cherry Chairside
 Table/Printer Stand

Leick
 Home
SINCE 1910

2219 S. 19th St.
 Sheboygan, WI 53081
 Ph: 920-451-4060
 Fax: 920-451-4063
info@leickfurnituresince1910.com



Hardware List

Item	Description	Qty
a	 Bolt 1/4" * 1-1/8"	2PCS
b	 Allen wrench	1PC
c	 Washer 1/4" * 12mm	2PCS
d	 Shelf metal clip	4PCS
e	 Door Pull	1PC
f	 Machine screw for door pull 5/32" * 3/8"	1PC


Parts List

Item	Description	Qty
A	Top Panel	1PC
B	Side Panel	2PCS
C	Front Frame	1PC
D	Back Panel	1PC
E	Adjustable Shelf	1PC
F	Bottom Panel	1PC

Assembly Instructions


step 1

Slide all the panels one by one, tap down until flush.




step 2

Bolt on top with 2 bolts.



step 3

Insert bottom panel and install shelf with shelf clips.



step 4

Install door pull.

