

ring



Pathlight
Smart Lighting

1. Set up your Pathlight.

Download the Ring app.

The app walks you through setting up and managing your Ring Pathlight.

Search for “Ring” in one of these app stores, or visit: ring.com/app



Set up your Ring Bridge.


The Bridge connects your Ring Smart Lights to the Ring app and the rest of your Ring devices.

To set up your Bridge, follow the instructions in the Ring app or the Bridge user manual.




Insert the batteries.

Push in the lock button on the front of your Pathlight, and slide off the battery cover. Then insert four D Cell batteries (not included), flat end first, into the battery compartment.



Set up your Pathlight in the Ring app.

In the app, tap **Set Up a Device**.
When prompted, select **Smart Lights** and follow the in-app instructions.
Once setup is complete, slide the battery cover back onto your Pathlight.




2. Install your Pathlight.

Place the stake.

Gently drive the stake into the ground at your chosen location.


Make sure the “Sensor Direction” arrow is pointing toward the area you want to monitor for motion.

i If you're installing multiple Pathlights, space them 5-7 feet apart for the best motion sensing performance.



Attach your Pathlight.

Lower your Pathlight onto the stake and twist clockwise until it clicks to lock it into place.



For additional help, visit: ring.com/help

Or give us a call...

[US 1 800 656 1918](tel:18006561918)

[Canada 1 855 300 7289](tel:18553007289)

[Worldwide +1 310 929 7085](tel:+13109297085)

For a list of all our customer support numbers, visit: ring.com/callus

To review your warranty coverage, please visit www.ring.com/warranty.

Patents: www.ring.com/patents

© 2019 Ring LLC or its affiliates.

RING, ALWAYS HOME, and all related logos are trademarks of Ring LLC or its affiliates.

Last updated: 01/04/19