



© 2017 Dorel Juvenile Group, Inc. Safety 1st™ and the Safety 1st logo and design are trademarks of Dorel Juvenile Group, Inc. Safety 1st™ y el logotipo de Safety 1st y su diseño son marcas comerciales de Dorel Juvenile Group, Inc. (800) 544-1108 www.safety1st.com
 Styles and colors may vary. Los estilos y los colores pueden variar. Made in CHINA. Hecho en CHINA.
 Distributed by (distribuido por) Dorel Juvenile Group, Inc., 2525 State St., Columbus, IN 47201-7494.
 Dorel Juvenile Canada, 2855 Argenta Road, Unit 4, Mississauga, ON, L5N 8G6 10/24/17 4358-6406B
 Importado y Distribuido en Chile por: Comercial e Industrial Sifa S.A. - San Ignacio 0201 / Parque Industrial Portezuelo Quilicura, Santiago Chile. Fono (562) 2339 9000. En Perú por: Comexa S.A. - Los Libertadores 455 - San Isidro, Lima -- Perú. Fono (511) 4469014.
 En Centro América, Caribe y Ecuador por: Best Brands Group S.A. - Av. Balboa, Bay Mall Plaza, Planta Baja, local 9, Panamá. - Fono: (507) 300 2884. En Colombia por: Baby Universe S.A.S. - Via 40 No. 77-29, Barranquilla, Colombia - Fono: (575) 353 1110
 Importador: DJGM, S.A. DE C.V. Gabriel Mancera No. 1041 Col. Del Valle Delegación Benito Juárez C.P. 03100 México, D.F. R.F.C. DJG1403056G9N Tel. (55) 67199202



Custom Fit All Purpose Strap

HS258, HS171, HS033, 48483 User Guide

! WARNING: Do not use this product to guard against toxic and dangerous substances, or sharp-edged or pointed objects. Such materials should always be placed “high up” or otherwise made completely inaccessible to children.
 ADULT INSTALLATION REQUIRED.


CAUTION: This product is only a deterrent. It is not a substitute for proper adult supervision. **DO NOT** use this product if damaged or broken. These products are not toys. **DO NOT** allow children to play with them. Not suitable for stoves and ovens, as a window lock or for use on interior or exterior doors. When possible, install out of reach of children. **FOR INDOOR HOME USE ONLY.**

Important Safety Information

Read all instructions before installing. Keep these instructions for future use. Check for security after installation. Your child will eventually be able to defeat this product. To keep this product effective for as long as possible, avoid letting children see how you operate child safety devices. Watching you disengage a lock, latch or cover could enable them to learn sooner how to defeat it.

BEFORE YOU BEGIN:

- Read all instructions before installing.
- Keep these instructions for future use.
- Remove all contents from packaging and discard box, and/or poly bags.
- Lay out and identify all parts.
- Do not return this product to the place of purchase. If any parts are missing, email support@djgusa.zendesk.com, or chat with us at www.safety1st.com. You can also call Consumer Care at (800) 544-1108. Have the model number ready (HS258, HS171, HS033, 48483) and date code (manufacture date) located on package.



IMPORTANT NOTE: For added security Part 2 is a permanent snap and cannot be opened once snapped shut.

To Install

BEFORE YOU BEGIN: Clean and dry all surfaces.

- 1 Determine where to install strap. Keep in mind that the strap can extend up to 6” (15.24 cm).
- 2 With Part 2 open, adjust the length of the strap to fit desired location.
- 3 Snap shut Part 2 over strap. Notches should fit in grooves to secure closure.
- 4 Remove paper backing from adhesive on Parts 1 and 2 and attach strap assembly to desired area. Press to adhere.
- 5 To open, squeeze two buttons together on Part 1 and remove strap. To relock, snap Part 1 back into place.

NOTE: Allow adhesive to cure for 24 hours before use.

To Remove

To Remove Permanently:

- Carefully pull edges of strap. Wipe off adhesive with a soft cloth and warm soapy water or roll adhesive off of surface with fingers and clean the surface according to manufacturer’s recommendations.

To Clean

Wipe with a clean, damp cloth.

Tira multiuso adaptable a medida

HS258, HS171, HS033, 48483 Guía del Usuario

! AVISO: No utilice este producto para evitar que los niños tengan acceso a sustancias tóxicas y peligrosas u objetos punzantes y cortantes. Tales materiales siempre deben colocarse en lugares “altos” u otros lugares a los que los niños no puedan llegar de ninguna manera.
 REQUIERE INSTALACIÓN POR PARTE DE UN ADULTO.


PRECAUCIÓN: Este producto solo funciona como dispositivo de seguridad. No sustituye la supervisión por parte de un adulto. **NO** use este producto si se encuentra roto o dañado. Estos productos no son juguetes. **NO** permita que los niños jueguen con ellos. No es apto para cocinas u hornos, ni como traba para ventanas o puertas interiores o exteriores. De ser posible, instálelo fuera del alcance de los niños.. **PARA USO DOMÉSTICO ÚNICAMENTE EN INTERIORES.**

Información de seguridad importante

Lea todas las instrucciones antes de instalar. Guarde estas instrucciones para su uso futuro. Un niño sin supervisión puede ser capaz de inutilizar la protección que ofrece este producto. Para que este producto funcione efectivamente durante más tiempo, evite que los niños vean como se opera. Si los niños ven cómo usted libera una traba, un pestillo o una cubierta, podrán aprender más rápido la manera de inutilizar cualquier tipo de dispositivo de seguridad.

ANTES DE COMENZAR:

- Lea todas las instrucciones antes de instalar.
- Guarde estas instrucciones para su uso futuro.
- Retire todo el contenido del embalaje y deseche la caja y/o las bolsas de polietileno.
- Despliegue e identifique todas las piezas.
- No devuelva este producto al lugar donde lo compró. Si falta alguna pieza, mande un correo electrónico a support@djgusa.zendesk.com o chatee con nosotros en www.safety1st.com. Además, puede llamar a Atención al cliente al (800) 544-1108. Tenga a mano el número de modelo (HS258, HS171, HS033, 48483) y el código de fecha (fecha de fabricación), que se encuentran indicados en el paquete.



NOTA IMPORTANTE: Para mayor seguridad, la pieza 2 es un cierre a presión permanente y no puede volver a abrirse una vez cerrado.

Para instalar

ANTES DE COMENZAR : Limpie y seque todas las superficies.

- 1 Determinar dónde instalará la tira. Tenga presente que se puede extender hasta 6 pulgs. (15,24 cm).
- 2 Con la pieza 2 abierta, ajuste la longitud de la tira para adaptarla al lugar deseado.
- 3 Cierre a presión la pieza 2 sobre la tira. Para asegurar el cierre total, las muescas deben encajar en las ranuras.
- 4 Desprenda la cubierta de papel adhesivo de las piezas 1 y 2 y coloque el montaje de la tira en el lugar deseado. Colóquelo a presión para adherirlo.
- 5 Para abrir, presione simultáneamente los dos botones de la pieza 1 y retire la tira. Para volver a trabar, vuelva a colocar a presión la parte 1 en su lugar.

NOTA: Deje que el adhesivo fragüe durante 24 horas antes de utilizar.

Para retirarla

Para retirarla de forma permanente:

- Tire cuidadosamente de los bordes de la tira. Limpie el adhesivo con un paño húmedo y agua jabonosa tibia o enrolle el adhesivo con los dedos para retirarlo de la superficie y limpie la superficie según las recomendaciones del fabricante.

Para limpiar

Limpie con un paño húmedo y limpio.